



MINI CATAPULT BONUS



1

Locate a paper clip (#1) and small pair of pliers.




2

Straighten the paperclip as shown.




3

Cut the large end off, making the legs as close to equal as possible. Save both sides.



4

Form a loop in the end of the longer piece as shown. This is the trigger pin.



5

Pry the ends of the 'U' shaped piece slightly apart.




6

Bend both ends of the 'U' shaped piece inwards. (Roughly 1/8" or 3mm)



7

Press the 'U' shaped piece into the hole on the underside of the throwing arm and squeeze the sides together. This is the trigger.



8

Lower the arm and slip the trigger pin through the trigger and into the hole in part 'F'. Voila!