



## INTRODUCTION

The perfect and first learning tablet for babies and toddlers! Every touch will be full of surprises, making learning a rich experience with auditory and visual interaction! With **Touch & Learn Tablet**, little ones will learn about the letters A to Z with their pronunciations, the spellings, singing along with the ABCs song, and challenging the exciting quiz and memory games. With two stages of learning levels to grow along with children! (2+ years)



# INCLUDED IN THIS PACKAGE

#### • 1 Touch & Learn Tablet

#### **ADVICE**

- For best performance, please make sure to turn the unit OFF before inserting or removing batteries. Otherwise, the unit may malfunction.
- All packing materials, such as tape, plastic, sheets, packaging locks, wire ties and tags are not part of this toy, and should be discarded for your child's safety.
- Please keep this user's manual as it contains important information.
- Please protect the environment by not disposing of this product with household waste.


## **GETTING STARTED**

Take the Touch & Learn Tablet out of the storage slot.

### **Battery Installation**

The Touch & Learn Tablet operates on 3 AAA (LR03) batteries.

- 1. Locate the battery cover on the back of the unit & open it with a screwdriver.
- 2. Insert 3 AAA (LR03) batteries as illustrated.
- 3. Close the battery cover and screw it back.



#### **Start Playing**

- 1. Once batteries are installed, switch on the system from **t** to **v** or **v** or
- 2. To turn OFF the system, just switch back to 😃 .

## SLEEP MODE

- If the Touch & Learn Tablet is not active for more than 2 minutes, it will automatically go into sleep mode to save power.
- To wake up the system, either reset by the Power Switch or the 2-stage Switch.

## **HOW TO PLAY**

### 1. Choose a learning level by the 2-stage Switch.

Once turned on the power, choose any learning levels by the 2-stage Switch.

Stage 1 is for basic challenges.

Stage 2 is for advanced challenges.



### 2. Select any of the modes to play.

There are 4 modes on the bottom of the **Light-Up Touch Screen**. Select then press any of the modes to play!



**Learning Mode** 



**Quiz Mode** 



**Music Mode** 



**Game Mode** 



### 3. Enjoy the game!

Follow the instruction to play! You can exchange the learning levels by the **2-stage Switch** at any time.



## **FOUR MODES TO PLAY**

Choose any one of the modes to play. Change the learning level for basic or advanced by **2-level Switch** at any time!



#### **Learning Mode**

Follow the instruction, then press an icon to hear what it is.

Stage In basic learning, it teaches the letters A to Z with their pronunciations, and words with playful sounds.

Plus 4 basic shapes (square, triangle, circle, and hexagon).

Stage In advanced learning, follow the lights to learn how to spell the words step by step.


Plus 4 core emotions (happy, sad, angry, and proud).



#### **Quiz Mode**

Challenge yourself with a series of questions related to the learning mode.

- 1. Follow the question, then press any icon to answer.
- 2. It will tell you the answer is correct or not by the voices and melodies.
- After three wrong tries, it will show you the correct answer by lighting up the icon(s).
- Stage In basic quiz, it will ask you to find a particular letter, word, or shape.
- Stage 2 In advanced quiz, it will ask you to spell a particular word or find the specific emotion icon.



- 1. Press any icon to make a sound effect while the ABCs song is playing.
- Once the song is over, you can press any letter icon to replay that part of the song. Or just press the music mode button again to replay the whole song.

Stage 1 In this stage, it will play the ABCs song with a vocal-on.

Stage 2 In this stage, it will play the ABCs song with a vocal-off.



#### **Game Mode**

How many lights can you remember? Give it a try!

- 1. Includes basic & advanced challenging levels.
- 2. In each round, you have three chances to try.
- 3. Once you lose a round, it will go back to the last level.
- 4. If you win three rounds in a row, it will go to the next level.
- A total of 5 levels: level 1 for two icons; level 2 for three icons; level 3 for four icons; level 4 for five icons; level 5 for six icons.
- Stage In basic level, remember the positions of the releasing icons, then find them by pressing the correct icons.
- Stage In advanced level, remember the positions of the releasing icons, then press the icons in the correct sequences.

## CARE AND MAINTENANCE

- Keep product away from foods and beverages.
- Clean with a slightly damp cloth (cold water) and mild soap.
- Never submerge the product in water.
- Remove batteries during prolonged storage.
- Avoid exposing product to extreme temperatures.

## **BATTERY SAFETY**

- Batteries are small parts and choking hazards to children, must be replaced by an adult.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the toy.
- Dispose of used batteries properly.
- Remove batteries from prolonged storage.
- Only batteries of the same type as recommended are to be used.
- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire, as batteries may explode or leak.
- DO NOT mix old and new batteries.
- DO NOT mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH) batteries.
- DO NOT recharge non-rechargeable batteries.
- DO NOT short-circuit the supply terminals.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.

## **TROUBLESHOOTING**

Symptom	Possible Solution
Toy does not turn ON or does not respond.	<ul> <li>Make sure batteries are correctly installed.</li> <li>Make sure battery cover is secured.</li> <li>Remove batteries and put them back in.</li> <li>Clean battery compartment by rubbing lightly with a soft eraser and then wiping with a clean dry cloth.</li> <li>Install new batteries.</li> </ul>
Toy makes strange sounds, behaves erratically or makes improper responses.	<ul> <li>Clean battery contacts per above instructions.</li> <li>Install new batteries.</li> </ul>



