

**deco**  **gear**



**Deco Gear RGB Gaming Mouse  
DGGMOUS**

**Thank you for purchasing your new Deco Gear Gaming Mouse with RGB Lighting (DGGMOUS.**

**This manual will review product specifications as well as using the RGB light effect functions.**

## **Product Specifications**

**Dimensions:** 4.8 x 2.7 x 1.6 in.

**Weight:** 4.6 oz (130 g)

**Sensor:** PMW3325

**Button:** 6 buttons

**Button Names:** left/middle/right/B4/B5/DPI

**Support:** USB online update

**Report Rate:** 1000 HZ

**DPI Level:** Indicated by different flashing colors

**PMW3325 DPI:** 800 red/1200 blue/1800 green/ 2500 orange/3200 purple/5000 cyan

## RGB lighting effect controls

At the same time, press the mouse Scroll Wheel + B4 to switch RGB lighting effects. The 11 options are listed below in cycle order:

1. Turn Off Mode
2. Constant Mode
3. Flash Mode
4. Breathing Mode
5. Neon Mode
6. RGB Wave Mode
7. Slide Mode
8. Movement Mode (LED remains off unless the mouse is moved)
9. Rolling Mode
10. Yoyo Mode
11. Cross Flashing Mode

Remember, to switch between modes press te Scroll Wheel and the B4 button (shown below) at the same time.

