



PRODUCT USAGE AND INSTRUCTIONS

FREESIP® TWIST STAINLESS STEEL

INSTRUCTIONS FOR USE:

- Wash before using.
- Hand washing is recommended to preserve finish.
- Do not use harsh chemicals (such as bleach, abrasives, etc.).
- To prevent leaking or spills, fill to just below the threads in the metal body.
- Visit OwalaLife.com for additional information.

CLEANING INSTRUCTIONS:

- Begin by separating pieces. Twist off the lid, then the spout. Pull straw out from the spout.
- There is a key mechanism in the middle of the lid made to align precisely with the spout for a perfect seal every time. Twist and pull this key mechanism *hard* to remove.
- Take out the gasket around the key mechanism and the ring gasket around the spout piece.
- Remove the carry loop before washing.
- The key mechanism, spout, both gaskets, and straw can all be placed in the utensil case of the dishwasher.
- Hand washing is recommended to preserve finish.
- For more information visit OwalaLife.com.

WARNINGS:

- Do not microwave, freeze, or boil.
- In order to minimize bacterial growth, do not use to store warm dairy products, baby food, or other perishable liquids.
- Drinking hot liquids presents a risk of injury.
- The straw allows generous amounts of liquid to be drawn suddenly into the mouth from the bottom of the bottle where the temperature of hot liquids is usually higher than it is at the liquid's surface.
- Never use with liquid hot enough to scald.
- Hot, carbonated, and perishable liquids and other contents may cause pressure to build up within the bottle and may leak or spray when opening the bottle.
- Always open with caution.