



Photon BB Conversions & Parts

There are 3 kinds of left BB cups:

- PHB005 BSA68-83mm left BB cup with nylon cover
- PHB006 B92/ BSA100 left BB cup with nylon cover
- PHB007 SA120mm left BB cup with nylon cover

There are 3 kinds of spindles:

- PHB009 68-83mm spindle (180mm spindle length)
- PHB010 100mm spindle (200mm spindle length)
- PHB011 120mm spindle (220mm spindle length)

There are 2 kinds of motor hangers:

- P3-B11A motor hanger plate
- P3-B11B motor hanger plate

There are 2 sets of spacers:

- P3-B36A 4mm spacer
- P3-B36B 7mm spacer

68-83mm	100mm	BB92	120mm
PHB005 BSA68-83mm left BB cup with nylon cover	PHB006 B92/ BSA100 left BB cup with nylon cover	PHB006 B92/ BSA100 left BB cup with nylon cover	PHB007 BSA 120mm left BB cup with nylon cover
PHB009 68-83mm spindle (180mm)	PHB010 100mm spindle (200mm)	PHB010 100mm spindle (200mm)	PHB011 120mm spindle (220mm)
P3-B11A motor hanger plate	P3-B11A motor hanger plate	P3-B11A motor hanger plate	P3-B11B motor hanger plate
P3-B36A 4mm spacer	P3-B36B 7mm spacer	P3-B36B 7mm spacer	P3-B36B 7mm spacer
		Black 3mm BB Spacer	
		PHB008 BSA to BB92 Adaptor	



Converting From One BB To Another

From To	68-83mm	BB92	100mm	120mm
68-83mm		Remove Black 3mm BB Spacer & PHB008 BSA to BB92 Adaptor PHB005 BSA68-83mm left BB cup with nylon cover PHB009 68-83mm spindle (180mm) P3-B36A 4mm spacer	PHB005 BSA68-83mm left BB cup with nylon cover PHB009 68-83mm spindle (180mm) P3-B36A 4mm spacer	PHB005 BSA68-83mm left BB cup with nylon cover PHB009 68-83mm spindle (180mm) P3-B11A motor hanger plate P3-B36A 4mm spacer
BB92	PHB006 B92/ BSA100 left BB cup with nylon cover PHB010 100mm spindle (200mm) P3-B36B 7mm spacer Black 3mm BB Spacer PHB008 BSA to BB92 Adaptor		Black 3mm BB Spacer PHB008 BSA to BB92 Adaptor	PHB006 B92/ BSA100 left BB cup with nylon cover PHB010 100mm spindle (200mm) P3-B11A motor hanger plate Black 3mm BB Spacer PHB008 BSA to BB92 Adaptor
100mm	PHB006 B92/ BSA100 left BB cup with nylon cover PHB010 100mm spindle (200mm) P3-B36B 7mm spacer	Remove 3mm BB Spacer & PHB008 BSA to BB92 Adaptor		PHB006 B92/ BSA100 left BB cup with nylon cover PHB010 100mm spindle (200mm) P3-B11A motor hanger plate
120mm	PHB007 BSA 120mm left BB cup with nylon cover PHB011 120mm spindle (220mm) P3-B11B motor hanger plate P3-B36B 7mm spacer	Remove Black 3mm BB Spacer & PHB008 BSA to BB92 Adaptor PHB007 BSA 120mm left BB cup with nylon cover PHB011 120mm spindle (220mm) P3-B11B motor hanger plate	PHB007 BSA 120mm left BB cup with nylon cover PHB011 120mm spindle (220mm) P3-B11B motor hanger plate	