

# Fiber Outdoor Side Chair

“One of the most difficult and noble disciplines of design is to create simple, functional and almost ordinary objects that nevertheless have a strong identity. The Fiber Outdoor Side Chair combines simple, embracing curves and a clear sculptural form manufactured using innovative materials, with a shell made from a minimum of 85% recycled plastic. In molding the chair’s shell, waste plastic is processed into high-quality granulates, creating a new take on modern outdoor furniture.”

— Iskos-Berlin



<b>Designed by</b>	Iskos-Berlin
<b>About the designer</b>	Iskos-Berlin is a Copenhagen-based design duo that has made international headlines within furniture, industrial and graphic design. The studio, formerly known as Komplot Design has collaborated with some of the world’s most prestigious manufacturers and their furniture, lighting and other design products are exhibited at numerous design museums around the world including MoMA and the Designmuseum Denmark.
<b>Environment</b>	Outdoor
<b>Country of Production</b>	Poland
<b>Preassembled</b>	Yes
<b>Description</b>	The Fiber Outdoor Side Chair brings a new perspective to modern outdoor furniture, with an innovative shell material made of a minimum of 85% recycled plastic. With each chair, a minimum of 2 kg of plastic waste is given new life. UV stabilizers are added to the shell’s composite, protecting the color of the chair from the wear and tear of outside life. The Fiber Outdoor Side Chair’s friendly, embracing curves provide extensive comfort with a functional and durable design.
<b>Material</b>	The shell of the Fiber Outdoor Side Chair consists of a minimum of 85% recycled plastic as well as UV stabilizers that keep color-fading at a minimum, protecting it from the impact of the sun. Tube base in galvanized steel with a weather-resistant deep matte powder coating. Plastic glides for outdoor use.
<b>Cleaning &amp; Care</b>	<p>When cared for properly, the Fiber Outdoor chair is designed to last. Follow these simple rules to care for your design in the best possible way. Clean the chair with a damp cloth. If necessary, use a mild detergent or dish-washing liquid, not concentrated. Always wipe with a dry cloth afterwards. To minimize the risk of stains and marks, liquids, grease etc. should be removed straight away. Lacquered surfaces can get scratches and chips if hit by other hard objects.</p> <p>To protect the chair from weather's harm when not in use, a cover suitable for a table with 6 chairs can be purchased separately. Please make sure that both the table, chairs and the inside of the cover is completely dry before putting the cover on. It is recommended to use a cover to protect the furniture from weather’s harm, especially during the winter season.</p>

# Fiber Outdoor Side Chair

## Dimensions

Height:	77 cm / 30.3"
Width:	49,5 cm / 19.5"
Depth:	53 cm / 20.9"
Seat Height:	46 cm / 18.1"
Seat Depth:	45 cm / 17.7"



[Explore Assets](#)

[DOWNLOADSITE](#)