

# HEXO MINI

07-Apr.-2017

## 1.0

PAR16 max. 15W | GU10 | 100-240VAC | 50-60Hz

CE IP20  $\leq 0.9m$

gold	300420G0
bronze	300420Q0
copper	300420P0
black texture	300420B0

### OPTIONAL

for PAR16 lamps see our catalogue

## 2.0

2xPAR16 max. 15W | GU10 | 100-240VAC | 50-60Hz


CE IP20  $\leq 0.9m$

gold	301420G0
bronze	301420Q0
copper	301420P0
black texture	301420B0


### OPTIONAL

for PAR16 lamps see our catalogue

HEXO MINI 1.0



HEXO MINI 2.0



## DIMENSIONS



HEXO MINI 1.0



HEXO MINI 2.0


## MOUNTING INSTRUCTION

- 1 Mount the base plate on the wall

## POWER CONNECTION

- 2 Connect the power supply.

Interior: STANDARD version






- 3 Mount inset on the back plate with side screws
- 4 Click cover over the inset

\* For optional locking, unscrew the grub screw app. 3mm. The cover is now stable.


- 5 Mount the bulb.

## FOR OPTIONAL LOCKING:

\* Lock the cover by unscrewing the grub screw app. 3mm. Then the cover is stable.



HEXO MINI 1.0



HEXO MINI 2.0

