



Panel 5 

Please read the instructions in full before assembly and note that all creases have been pre-folded.

Step 1. Take Panel 2 and Panel 4 and prefold all the side and roof Flaps.

Step 2. Take Panel 1 and Panel 3 and interlock all **A** Tabs into the **A** Slots on Panel 2, creating a U shape. Push the Tabs until they are securely locked into the Slots.

Step 3. Take Panel 1, 2 and 3 and interlock all **B** Tabs into the **B** Slots on Panel 4. Push the Tabs until they are securely locked into the Slots.

Step 4. Once all the **A** and **B** Tabs and Slots are interlocked, fold both the roof sections down, interlocking all **C** Tabs and Slots, tucking in the section highlighted in yellow.

Step 5. Fold the Chimney piece into a square and push the **D** Tabs into the **D** Slots of the roof.

Step 6. Your Playhouse is now ready ! Decorate it with Wax Crayons or Felt Tip Pens and enjoy !

