



# Baby Fish Toy



## User Manual

- Charge battery with USB provided, ensuring the battery is switched to "off" while charging. A red light should appear to indicate charging.
- Charge for approx. 1 hour.
- Turn the switch on battery to "on"
- The fish should move for anywhere from 15-30 seconds and will stop until it is interacted with again (particularly when touching the tail).  
Overall it should hold its charge for approximately half an hour to an hour depending on how much it's played with.

## Connect with us

-  @peachyandpear
-  @peachyandpear
-  hello@peachyandpear.com