

Corniche Aluminium Roof Lantern

SURVEYING GUIDE

- Eaves to sit flush on the external upstand.
- Ensure upstand is level and square.
- It is the responsibility of the installer to determine the finishing detail of the inside.



Download the installation guide at www.korniche.co.uk



www.korniche.co.uk