KITTY DESKTOP VACUUM CLEANER

FRONT OF DEVICE

Light

When in use: White light
When charging: Flashing red light
When fully charged: Red light
When battery is low: Flashing white light

Bottom cover

Twist clockwise to open the bottom compartment.
Twist counter-clockwise to close.
Clean with water.

Power button

Press once for light-vacuum.
Press twice for medium vacuum.
Press a third time for strong vacuum.
Press a fourth time to turn the vacuum off.

USB-C port

BACK OF DEVICE

Device specifications

Battery capacity	800mAh
Rated input	5V=0.65A
Executive standard	6B4706.1
Product weight:	0.66 lb (0.30kg)
Product size:	3.54x3.54x3.54 in (86x86x92mm)

Still have questions?
E-mail us at support@multitasky.com!

⚡ multitasky