



THE MACARON POWER BANK / HAND WARMER

USER MANUAL USER MANUAL USER MANUAL USER MANUAL USER MAN

Indicator Light



On/off button

Press once to activate the hand warmer function (113°F). [Indicator light will be white.]


Press again to increase the temperature (131°F). [Indicator light will be orange.]

Press a third time to turn off the hand warmer function.

USB-C port

Indicator light will flash blue when charging.

Hand warmer function cannot be activated while the device is charging.



Feeling warm and charged has never been so sweet

Still have questions?
E-mail us at support@multitasky.com!

 **multitasky**