



THE TRAVELER POWER BANK/ HAND WARMER

USER MANUAL

USB Port



MicroUSB Port

Battery Indicator Light

100 - 70%	White Light
70 - 30%	Green Light
> 40%	Orange Light
> 5%	Flashing Orange Light

No light will be visible when the device is out of power.

Switch

Short-press once to turn on the hand-warmer function (113°F)

Short-press a second time to increase the temperature to 131°F.

Short-press a third time to turn off the hand-warmer function.

Long-press for 3 seconds to display the battery level via the indicator light.

