



VP-18AL

REPAIR PARTS

No.	Description	Part No.
1.	2" Pressure Valve Kit	VP 2.0 CYL KIT
2.	2" Lock Ring	VP 3.107
3.	2" Jet Barrel	VP 3.103 JET
4.	Safety Release Valve	VP 5.102-145
5.	150 PSI Gauge	VP 1.106-150
6.	Safety Button Cover	VP PB SAFETY
7.	Viper Release Button	VP TRIGGER

Order parts from your distributor or jobber.
When ordering parts always give the following information: Part number, description and serial number of your machine.

PCL Connector is NOT INCLUDED must be purchased separately.

Reminder: Always exercise caution when using compressed air.