



Boogie®

Lockholder Install

www.boogiebikes.com

1-833-266-4432



1. Open your package and check to ensure all the parts needed are included:

In addition, a phillips-head screwdriver is required





2. Seperate the top and bottom pieces of the lockholder by turning the top screw counterclockwise



3. Remove the four small screws on the corners of the Lock Carrier, seperating the piece into three parts: Carrier (1) and Foot Brackets (2)



Note: the screws are short so hold onto them when unscrewing!



4. Turn off and remove Battery, then place one Foot Bracket face-up on the middle bar (the holes for the screws should be visible)



5. Place Carrier on top of middle bar so that the two screw-holes are lined up with those on the grip underneath





6. Place screws in and tighten with screwdriver



7. Repeat steps 4 and 6 by placing the second Foot Bracket underneath the middle bar, lined up with the Carrier, then fasten final two screws in place





8. Place Lock on mount

Note: the middle section of the battery may need to be moved so that it rests on the mount as seen in the picture, this ensures that the top piece will fit on top



9. Fasten Lock Clamp back onto mount by twisting in screw





10. Ensure that lock is secure and enjoy!