



LINDERMAN
BUILDS

CUSTOM CONCRETE FIRE FEATURES

FIRE-TABLE SET-UP

- PLACE FIRE-TABLE IN LOCATION
- LEVEL FIRE-TABLE
- CONNECT SUPPLY LINES (FLARE CONNECTIONS)
- TEST BURNER SOUND BY OPENING VALVE ON SIDE
**ADJUST SHUT OFF VALVE AT SUPPLY IF A WHISTLING GAS PASSING THROUGH BURNER HOLES IS NORMAL.
- LOWER ALUMINUM PAN INTO PLACE AND LIGHT BURNER
- IF FLAME HEIGHT IS BETWEEN 10-16" WITH NO WHISTLING NOISE THEN VALVE IS ADJUSTED CORRECTLY FOR OPTIMAL PERFORMANCE.
- ADD LAVA ROCKS / MEDIUM UNTIL 3/4" BELOW TOP HEIGHT. LOWER IF YOU HAVE IPE OR ALUMINUM TOPS.
- ALWAYS IGNITE THE BUTANE LIGHTER FIRST AND HOLD OVER LAVA ROCKS BEFORE OPENING GAS VALVE.
- ENJOY.

