



**CLEAN AIR
STARTS
HERE.**



Table of Contents

Welcome Letter	2
Safety Instructions	3-4
Getting Started	5
Features & Controls	6-7
SmartPure Technology	8-9
Filters	10
Support & Warranty	11
Share Your Experience With Sans	12

Welcome to Sans! We're thrilled to share with you our passion for creating a cleaner, healthier home.

Sans was designed to be a simple solution to a multitude of issues people face in their homes and lives. We've aimed to join science, simplicity and design every step of the way and are certain that you'll love Sans as much as we do.

To clean air and healthy spaces!

Sans founders,

Adam Bedford

John Fanelly



Important Safety Instructions

PLEASE READ AND SAVE THESE INSTRUCTIONS

Warning

Please follow these instructions to avoid a risk of fire, electric shock, or personal injury.

- Make sure Sans is unplugged before any maintenance or cleaning.
- Never put fingers or body parts inside the machine.
- Do not allow water, liquids or flammable cleaning products inside the machine.
- Do not put oils, incense or perfumes inside the machine or filter.
- Unplug and cease use if the plug, power cord or machine is damaged.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

Maintenance


- Use a soft cloth and optional neutral cleaning product to wipe down the exterior of the machine.
- As needed, unplug the device, remove the filter and lightly wipe the surface with a soft cloth to remove any dust, debris and hair.
- Do not attempt to vacuum or wash the filter. Replace the filter every three months.
- Make sure that the air inlet and outlet is not blocked or obstructed. Leave at least 12 inches of space around the back and sides of the machine while also leaving at least 20 inches of space above the machine.

Getting Started

To begin using your new Sans air purifier, it is necessary to remove the packaging surrounding the filter. The filter is accessible through the panel on the back of the device. Locate the handle on the back panel and simply press down on the top of the handle to release and remove.



Features & Controls



Features & Controls cont.

The top control panel houses the following features and controls:



On/Off - Control the power to your Sans purifier.



Mode/Fan Speed - Switch between Auto Mode (Sans auto-adjusts fan speed based on your air quality) and Manual (low, medium and high fan speed).



Sensor Mode - Switch between showing PM2.5, PM10, and VOC indexes on the display (view only, all contaminants are always being detected & filtered).



Timer - Program your Sans purifier to run for 2, 4 or 8 hours before shutting off.



Light/Child Lock - Cycle between high, low and off. Hold for 3 seconds to activate or deactivate child lock. When on, all buttons are disabled.




UV Light/Filter Replacement - Turn the UV light on/off. When the LED above this button is illuminated, the UV light is activated. The light is internal and not visible from the outside. This LED will also flash red when it is time to replace the filter.

SmartPure Technology

SmartPure technology constantly senses the air quality in your space and adjusts filtration accordingly.

Additionally, with SmartPure, you can see Sans work through the digital display on top of your air purifier.

Tap the Sensor Mode button (🔍) to cycle between indexes.



SmartPure Technology cont.

What do the numbers and colors mean?

Sans detects three different types of harmful particles:

Index	Scale	Color	Rating
PM 2.5	0-75	Blue	Good
	76-150	Yellow	Moderate
	151+	Red	Poor
PM 10	0-75	Blue	Good
	76-150	Yellow	Moderate
	151+	Red	Poor
VOC	0-300	Blue	Good
	301-800	Yellow	Moderate
	801+	Red	Poor

NOTE: This light is not the UV light, which is internal and facing the filter.

Filters

When the filter in Sans requires replacement, a blinking red light will appear above the UV light button.

Join our Clean Air Club filter subscription for automatic filter replacements right when you need them, with free shipping. Visit livesans.com/club to learn more.

Changing your Sans filter

Replacing a used filter with a new one is straightforward. Simply remove the rear door on your Sans purifier, pull out the old filter by the fabric tabs at either end in a downward motion and replace it with the new one.

A video of this process is available here: livesans.com/replace-filter



After replacing the filter, press and hold the UV light button for 7 seconds to reset the internal timer and stop the blinking light.

Support

We are always here to help answer questions or provide guidance on how to get the most out of your Sans purifier. See below for how to get in touch.

- Email us at hi@livesans.com.
- Visit our website to use the Live Chat feature.

Warranty

Sans includes a 5-year warranty for your complete peace of mind. Visit livesans.com/warranty to register.

Share Your Experience with Sans!

Here are a few ways you can show your love for Sans.

Write a Review


Look out for an email from us asking for your feedback or visit breathesans.com/review.

Tag us on Instagram

Share a photo of Sans in your space and tag us. We're @breathesans on Instagram!

Referral

Share a \$40 off coupon with your friends and get your next filter on us. Visit breathesans.com/referral to learn more.





sans



livesans.com



hi@livesans.com



[@breathesans](https://www.instagram.com/breathesans)