Hulas 💨 l

CARE AND MAINTENANCE

CLEANING

Canopy and cover

- Clean the Hulasol canopy and cover using lukewarm water and a PH-neutral mild detergent.
- Wipe carefully using a soft brush. Never use a high-pressure washer to clean the Hulasol canopy.

Frame and base

Clean the frame and base with a soft damp cloth.

Hostile environment

With intensive usage of the products in a hostile (sea, sand, chlorine, ...) environment, we advise that you regularly (1x/quarter) rinse the canopy, frame and base using fresh water to prevent the build-up of salt residue.

SMART USE

Water

Always unplug the 230V (or 120V) plug before connecting/releasing other connectors and cover the connectors with the protective hoods to prevent ingress of water or dust.

Wind

We advise to always close the Hulasol whenever wind speeds exceed 50 km/h or 31 mph (6 Beaufort).

STORAGE

Canopy and cover

Never place the cover on the Hulasol when it's wet, this causes mildew.

Battery pack

- Waterproof cover is included for safe storage when battery is stored or charged indoor.
- We advise to store the battery at a temperature between 10 and 20°C (between 50 and 68°F) and fully charged.

