


regalo[®]

24pk Outlet Plugs 6100 W





Feature

- Is suitable for sockets.
- Prevents babies from inserting their fingers or objects into sockets.
- Helps prevent electrical shocks.

Installation

Step 1: Install outlet cover into electrical outlets.

Step 2: To remove, insert key into outlet cover, then twist and pull.



WARNING: For use with children 3 years of age or up. Keep key out of reach from child. This product is used as a deterrent, adult supervision is required. When not in use, keep out of reach from child. Discontinue use when child is able to remove. Discontinue use if plug does not tightly fit. Do not use if outlet is worn or damaged.