

regalo[®]

2pk

Cabinet Lock 6131 W



Feature



- Easy to use cabinet lock.
- Keeps cabinet doors secure.

Installation

Step 1: Press sides of catch while sliding away from lock to unlock.

Step 2: Insert lock through cabinet handle. Slide catch against handle to secure in place.

Care & Maintenance: Make sure device is securely attached and kept clean using a damp cloth. When device is no longer in use, remove by peeling it away from item and keep out of reach from children.



⚠ WARNING

FAILURE TO FOLLOW THESE WARNINGS AND THE INSTRUCTIONS COULD RESULT IN DEATH OR SERIOUS INJURY. KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE. THIS PRODUCT IS ONLY TO BE USED WITH WOOD CABINET DOORS AND DRAWERS. READ THESE WARNINGS AND THE INSTRUCTIONS CAREFULLY BEFORE INSTALLING AND USING THIS DEVICE. • ADULT INSTALLATION REQUIRED. KEEP SMALL PARTS AWAY FROM CHILDREN DURING INSTALLATION. • PROPERLY STORE ANY EXTRA OR UNUSED COMPONENTS OUT OF REACH OF CHILDREN. • THIS DEVICE IS INTENDED TO RESTRICT ACCESS BY YOUNG CHILDREN TO THE CONTENTS OF A CABINET OR DRAWER, BUT SOME CHILDREN MAY STILL BE ABLE TO DEFEAT IT. • REPLACE THE DEVICE IF IT BECOMES DAMAGED OR BROKEN OR FAILS TO FUNCTION PROPERLY