



SOCIAL ENTROPY • ELECTRONIC MUSIC INSTRUMENTS

TECH NOTE

INSTALLING ENGINE EXPANSION BOARDS

ENGINE can be expanded with optional expansion boards that are installed inside the machine.

To install an expansion board, the existing blank panel must be removed. To remove the blank panel, use the included hex wrench to remove the two screws holding the panel in place. Take care not to let the panel rotate and scratch the finish of the machine.

Once the blank panel is removed, the expansion board must be fitted into the machine. Depending on the type of the expansion panel, various ribbon cables will need to be plugged into connectors inside the chassis, please see the instructions for the specific expansion board for details on the ribbon cables.

After the cables are connected, carefully slide the expansion board into the chassis. Use the screws and hex wrench to secure the expansion board in place.

ENGINE must be configured to recognize the new expansion board. To configure ENGINE, power on the machine while holding the EXP MODE (STEP 9) button. Rotate control knob 1 to select the type of installed expansion board.

Power off and on ENGINE to use the expansion board.