



Microphone Failure



Not working?

Surface Cleaning



Not working?

Replace **microphone or charging board** containing it.



Not working?

Replace interconnection flex.



Not working?

Measure on Diode Scale on **C1113, C1114 and C1117**, and pins **30, 32** and **32** on FPC **J2901**.



Open Line?

Make communication jumpers.

<b>AP</b>	Applications Processor	<b>Q</b>	Transistor
<b>C</b>	Capacitor	<b>R</b>	Resistance
<b>D</b>	Diode	<b>TP</b>	Test Point
<b>FL</b>	Filter - Coil	<b>U</b>	Integrated Circuit
<b>FPC</b>	Connector	<b>V</b>	Voltage
<b>GND</b>	Ground	<b>VBATT</b>	Battery Voltage
<b>J</b>	Connector	<b>VBUS</b>	USB Voltage
<b>L</b>	Coils	<b>VCC VDD</b>	Positive Voltage
<b>LDO</b>	Low Differential Regulator		