


物料名称：AM-223三脚架说明书
物料编号：PT414-1
材质：100g双胶/CMYK四色印刷
展开尺寸：504x210mm
成型尺寸：72x105mm

说明书正面



Instructions
AM-223 Tripod

GUANGDONG SIRUI OPTICAL CO., LTD.
Add: The Third Industrial District, Wugushan Town, Zhongshan City, Guangdong, China (Zip Code: 528453)
Tel: 86-760-8887373 Fax: 86-760-88207062
E-mail: info@sirui-photo.com Website: www.sirui.com

- 1. Know the product**
Mounting Screw, Accessory Connecting Screw Hole, Rubber Cover, Adapter Plate, Spider, Semi-automatic Pull Button, Supporting Leg, Twist Leg Lock, Rubber Foot.
- 2. Leg Angle Adjustment**
Folded down, Hold the tripod, and pull the Button A along the direction of arrow as shown in figure to adjust the leg angle to the desired position. Pull up the leg until the Button A returns automatically. After the Button A returns automatically, the leg angle can be adjusted as needed. The leg can be adjusted to three angles (Or Lift up the legs to your desired angle. Press the top of the Button A and the Button A will come to the corresponding position to fix the leg angle as desired.)
- 3. Leg Extension and Retraction**
Pull the leg up to the first angle. Twist the Leg Locking Button B about 45 degree to the left direction. The leg can be extended or retracted easily. Adjust the leg to the desired height, and tighten the Leg Locking Button B to the opposite direction to lock in position.
- 4. Replace the Rubber Feet with the Stainless Steel Spikes**
Detach the Rubber Feet and replace them with the Stainless Steel Spikes.
- 5. Switch Mounting Screw from 3/8" to 1/4"**
Loosen the Mounting Screw D with the included Allen Wrench E. Loosen the Adapter Plate F and take it out. Remove the Mounting Screw C. Invert the Mounting Screw C and insert it into the screw hole of the Adapter Plate F. Rotate the Adapter Plate F, and screw on it. Then tighten the Mounting Screw D with the included Allen Wrench E.
- 6. Tightness Adjustment of Legs**
Slightly adjust the Screw G to get your desired stability and tightness with the Allen Wrench H if the supporting leg of the spider is too tight or loose.
- 7. Screw Hole for Accessories Connection**
Attach photography accessories that fit with 1/4" Screw Hole.

WARRANTY CARD INFORMATION

Dear SIRUI Customer, Thank you for your purchase of SIRUI Professional Product! SIRUI warrants that your purchase is free from defects in materials and workmanship under normal use during the Limited Warranty Period. The Warranty begins on the original date of purchase on your sales receipt and is not transferable. If service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty Length
Tripods / Monopods / Accessories	6 years
Humidity Control Cabinet (Cabinet)	3 years
Humidity Control Cabinet (Electronics)	3 years

Model: _____ Date: _____
Store: _____ Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in.

SIRUI offers a 1 Year Limited Warranty (3 Year Warranty for Electronic Parts). This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distributor option of defective parts. Fee of charge (except the cost of transportation to the distributor/service center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and Questions. SIRUI will not be responsible for expenses or inconveniences, or consequential damages to equipment, or by breach of any expressed or implied warranties.

Limitations: Warranty is not transferable. This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases:
1. If the equipment has been serviced by other than an authorized SIRUI Service Center.
2. Damage to the equipment is due to modification (including but not limited to, the removal of ballhead/clamps), overloading, mishandling, abuse, accident, sand, corrosives, water damage or not following operating instructions.
3. No valid proof of purchase is provided.
4. Damage caused by acts of nature (including, but not limited to fires, floods or earthquakes).

Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.

Warranty Address and Contact Information: Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.)

1. Guangdong SIRUI Optical Co., Ltd.
The Third Industrial District, Wugushan Town, Zhongshan City, Guangdong, China
Tel: 0086-760-8887373 Fax: 0086-760-88207062
http://www.sirui.com E-mail: info@sirui-photo.com
Service Hotline: 0086-400-8302258
Complaint Hotline: +86-181-6563-9388
(Monday to Friday, 9:15am-12:15pm, 14:00pm-18:00pm)

2. SIRUI USA, LLC
Add: 29 Commerce Court Verona, NJ 07044
www.sirui.com
Service: Toll Free 866-373-0829 E-mail: info@sirui.com
FOR PRODUCTS PURCHASED IN THE USA PLEASE SEE:
For full details on USA Warranty Terms and Limitations:
https://www.siruiusa.com/warranty.html
To register products: https://www.siruiusa.com/product-registration.html


3. European Service Center
Add: SIRUI Optical GmbH • Ernst-Augustin-Str. 1a • 12489 Berlin • Germany
Phone: +49 30 991 94 00 • Email: info@sirui-optical.eu

Specifications are subject to change without notice.

Attention:

- Do not exceed the recommended load limit of the head and/or tripod. (Please refer to product specifications.)
- Please make sure that the locks are securely tightened when in use.
- This product should not be used in environments that exceed the following conditions: (-40 ~ +100°C / -40 ~ +212°F). And, when used in damp, dirty or dusty environments, please clean and dry thoroughly after use, to assure proper functioning in the future. It is not recommended to expose this product to saltwater. If exposed, please clean with mild soap and warm water and towel dry.
- Please keep from high temperatures and direct exposure to bright sunlight for extended periods of time.
- Please do not leave the equipment alone in a public place, which can be an inconvenience or hazard to others.
- To protect your camera gear, please remove it from the tripod/ball head when transporting from place to place.
- Please use a soft towel with warm water and mild soap to clean the locking system and gliding parts when necessary. Towel dry before storing the tripod.
- Under most situations, there is no need to lubricate any parts of this product. The addition of most lubricants will gum up the mechanisms and reduce their normal gliding characteristics. Please call or email us if you have any questions or special needs.
- Please keep this product away from all electrical power sources.

说明书背面



使用说明
AM-223三脚架

广东思锐光学股份有限公司
地址: 广东省中山市五桂山第三工业区 邮编: 528458
电话: 0760-8887373 传真: 0760-88207062 服务热线: 400-830-2258
邮箱: info@sirui-photo.com 网址: www.sirui.com
邮编: 1516050088
(收稿日期: 15-12-15, 14:00-18:00)

- 1. 认识产品**
大小螺丝, 附件螺孔, 附件螺孔盖, 转接平台, 本体, 半自动拉钮, 支撑脚, 脚管松紧旋钮, 包胶脚垫.
- 2. 三脚架展开及角度调节**
收脚状态, 手拿起脚架, 如图箭头所示, 将拉钮朝图中箭头方向所有方向拉动至完全定位后即可. 手拿脚管至拉钮, 如图箭头所示, 拉钮朝图中箭头方向按一下拉钮, 即可使脚管的角度卡位锁定.
- 3. 三脚架脚管伸缩**
将脚管拉至第1级使用角度. 手拿脚架正面操作, 向左转动脚管松紧旋钮45度后, 脚管就可以自由伸缩, 当调整好高度位置后, 向反方向拧松脚管松紧旋钮即可锁定位置.
- 4. 金属脚钉与包胶脚垫互换**
当需要用到金属脚钉时, 先将脚架上的包胶脚垫拆下后再安装金属脚钉.
- 5. 相机平台大小螺丝3/8转1/4**
用六角扳手松开脚管固定螺母, 拧松转接平台并旋转取出. 取出大小螺丝, 将大小螺丝插入转接平台并装入六角脚垫, 拧紧并旋转转接平台并拧紧固定螺母.
- 6. 脚管松紧微调**
当发现支撑脚与本体有过紧或过松的情况时, 可以通过脚管松紧微调旋钮进行微调至您所需要的稳定性和力度.
- 7. 附件螺孔**
附件安装螺孔可以安装与1/4"螺孔匹配的相关附件.

保修卡

尊敬的顾客:
感谢您购买思锐的产品!在正常使用过程中,如果因器材本身的材料及工艺出现质量问题,思锐将会提供免费的保修服务。在需要保修服务时,请提供保修卡和购买凭证(收据或发票,须有商家盖章),思锐公司将售后服务热线:400 830 2259

产品名称	保修期限
脚架	6年
云台	6年
防潮柜本体	6年
电子部分	3年

产品型号: _____ 购买日期: _____
商店名称: _____ 商店电话: _____
商店地址: _____
商店盖章: _____

顾客须知:

- 思锐产品,享受6年免费保修(电子部分为3年),保修时间从购买之日起算;
- 所修产品,必须是思锐正式授权的经销商或电子商务处购买;
- 需寄回思锐工厂维修的,请先拨打思锐服务电话,待确认故障后,思锐公司承担来回运费。一般性故障可在7个工作日内完成维修并寄回;
- 防潮柜的保修:请先确定发生问题的部件,把该部件卸下单独寄回思锐工厂维修即可。具体可参照使用说明书或致电服务热线。
- 以下情况不在保修范围:
① 超过保修期限的;
② 在非思锐正式授权经销商处购买的;
③ 在未报思锐授权的代理商或维修中心维修过的;
④ 由于不正当操作、意外时间、自然灾害导致的故障或损伤。

※本保修卡只限在中国大陆使用

注意事项:

- 不要超过最大的制定负重(请参考个别产品说明);
- 当使用产品时,时常紧固其安全装置;
- 切勿在温度低于零下40摄氏度及高于100摄氏度使用。当在潮湿、沙地、布满尘埃的环境下使用后,请记得将产品弄干及清洁,不建议在海水下使用;
- 切勿将产品长时间放在阳光下暴晒及避免高温环境,例如长时间放在车内或玻璃窗边;
- 在公众地方使用时,如在没有人照料下,切勿留下设备而引起其他公众不便;
- 建议在运输过程中,将设备(例如相机)从脚架上移除;
- 使用温和清洁剂及柔软毛巾清洁,将尘埃及沙粒从所有锁扣及活动部件清除;
- 除非有需要,此设备无需定期添加润滑油,如确实需要时,请使用标准润滑油或油;
- 为自身安全着想,切勿将产品接触任何电源。

说明书折叠方法:

