


图纸名称：思锐VA-5说明书
物料编号：YV37-1
材 质：100g双铜纸
展开尺寸：504x210mm
成型尺寸：72x105mm

说明书正面：



INSTRUCTIONS
VA-5
Professional Fluid Video Head

GUANGDONG SIRUI OPTICAL CO., LTD.
Address: The Third Industrial District, Wuguihan Town, Zhongshan City, Guangdong, China (Zip Code: 528488)
Tel: 86-760-8897373 Fax: 86-760-8507082
E-mail: info@sirui-photo.com Website: www.sirui.com

VA-5 Data Chart

Maximum Counterbalanced Weight	1/2.2
Weight (kg/lb)	3/6.61
Specifications (mm)	VA-5 300x120x83 0.6/1.32 3/6.61

WARRANTY CARD INFORMATION

Dear SIRUI Customer, Thank you for your purchase of SIRUI Professional Product! SIRUI warrants that your purchase is free from defects in materials and workmanship under normal use during the Limited Warranty Period. The Warranty begins on the original date of purchase of your sales receipt and is not transferable. If service is required, a copy of the sales receipt must be included with an explanation of the problem.

Product	Warranty Length
TriPods/Monopods/Accessories	6 years
Humidity Control Cabinet (Cabinet)	3 years
Humidity Control Cabinet (Electronics)	3 years


Model: _____ Date: _____
Store: _____ Serial Number: _____

Warranty coverage can differ from region to region. Please see the contact information below for product registration, information and service for the region the product was purchased in. SIRUI is a USA Limited Warranty (3 Year Warranty for Electronics Parts). This warranty shall be limited to repair, adjustment and/or replacement at SIRUI or its authorized distributors' option, of defective parts, free of charge (except the cost of transportation to the distributor/service center). Responsibility is limited to the actual cost of the item. Call or Email with questions and service before sending any product to the center in your region. Below is a listing of contact information for Product Registration, Service Inquiries and Questions. SIRUI will not be responsible for expenses or consequential, or consequential damages to equipment, or by breach of any expressed or implied warranties.


Limitations:
Warranty is not transferable.
This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases:
1. If the equipment has been subjected to more than an authorized SIRUI Service Center.
2. Damage to the equipment is due to modification (including but not limited to, the removal of factory-installed components), overloading, mishandling, abuse, accident, fire, corrosion, water damage or not following operating instructions.
3. No self-repair or purchase is provided.
4. Damage caused by acts of nature (including, but not limited to, floods or earthquakes).

Warranty coverage can differ from region to region. Please see contact information below for product registration, information and service for the region the product was purchased in.


Warranty Address and Contact Information:
(Please contact the seller or the local distributor where the product was purchased for warranty issues or questions and before any product is sent.)
1. Guangdong SIRUI Optical Co., Ltd.
The Third Industrial District, Wuguihan Town, Zhongshan City, Guangdong, China
Tel: 0086-760-8897373 Fax: 0086-760-8507082
http://www.sirui.com E-mail: info@sirui.com
FOR PRODUCT PURCHASED IN THE USA PLEASE SEE:
Service Center: 1-800-833-2288
Complaint Hotline: +86-181-85631388
Monday to Friday: 9:30am-12:15pm, 14:00pm-18:00pm
2. SIRUI USA, LLC
29 Commerce Court Verona, NJ 07044
www.sirui.com
Service Toll Free: 866-373-0939 E-mail: info@sirui.com
FOR PRODUCT PURCHASED IN THE USA PLEASE SEE:
Service Center: 1-800-833-2288
Complaint Hotline: +86-181-85631388
Monday to Friday: 9:30am-12:15pm, 14:00pm-18:00pm
To register products: <https://www.sirui.com/product-registration.html>
3. European Service Center
Address: SIRUI Optical GmbH • Ernst-Augustin-Str. 1a • 12489 Berlin • Germany
Phone: +49 30 991 94 90 • Email: info@sirui-optical.eu




Know Your Video Head
Quick Release Clamp
Quick Release Locking Knob
Upper Release Level
Security Pin Release Button
Quick Release Plate
Panning Bar
Horizontal Panning Lock Knob




Attaching and removing the Quick Release Plate from the head




Attaching and removing the Quick Release Plate from the camera or video camera




Use of head during video shooting




Attaching the camera or video camera onto the head




Adjusting the balance of the camera or video camera on the head



Removing the Quick Release Plate from the head



Removing the camera or video camera from the Video Head



Placing the head into the storage bag

Precautions:

- When attaching the camera or video camera onto the video head, please hold the camera or video camera securely to prevent accidentally dropping your equipment.
- When attaching the video head onto the tripod, please hold the video head securely, to prevent accidentally dropping the head.
- Temperature usage range: -20°C ~ 60°C (-4°F ~ 140°F).
- Tilt angle of the head: -60° ~ +90°.
- When the balance is set, if you attach additional accessories, you will need to re-adjust the horizontal balance.

1. Know Your Video Head

2. Attaching the video head

- To attach the video head onto the tripod, you must make sure the mounting screw of your tripod is 3/8". If it is 1/4" you will need to get a 3/8" screw or adapter. Many professional tripods have reversible mounting screws. Please check your tripod manual for more details.
- Tighten the Horizontal Panning Lock Knob, to lock the head and prevent it from turning. As shown in Figure 2, align the 3/8" mounting hole at the bottom of the Video Head with the 3/8" screw on the tripod. Hold by the base of the Video Head and rotate the Video Head in a clockwise direction until it is locked tightly.

3. Removing the Quick Release Plate from the head

As shown in Figure 3, loosen the Quick Release Plate Locking Knob. Then you can remove the Quick Release Plate from the clamp by moving it forwards or backwards.

4. Attaching the Quick Release Plate onto the Camera

As shown in Figure 4, attach the 1/4" or 3/8" screw into the tripod socket of the camera by turning in a clockwise direction. To remove the tripod screw that is not required, before attaching the QR plate onto the camera, pull out the rubber plug on the bottom of the QR plate and slide out the screw. Replace the rubber plug to prevent loss of the remaining screw.

5. Attaching the Camera with QR Plate onto the head

As shown in Figure 5, (after you have loosened the QR Plate Locking Knob by turning it counter-clockwise), slide the QR Plate laterally into the Quick Release Clamp and tighten the clamp by turning clockwise. You can slide the QR Plate into the clamp from either side. Caution: Before you release your camera, please make sure the QR Plate is properly seated in the Quick Release Clamp and the Quick Release Locking Knob is tightened.

6. Balance adjustment on the head with camera attached

As shown in Figure 6, loosen the Quick Release Clamp Locking Knob, move the camera backwards or forwards until the bubble level on the clamp is centered and lock the Quick Release Clamp Locking Knob. Caution: Before you make the Balance Adjustment, please make sure the tripod is level by checking the bubble level on the panning base of the video head.
Note: You may need a longer QR Plate for bigger camera systems. SIRUI has a wide selection of Arca-compatible TY-Series Quick Release Plates to choose from.

7. Using the VA-5 when shooting videos

- The VA-5 has a strong counter-balance system that provides up to 1kg (2.2 lb) of resistance. As shown in Figure 7, by turning the Tilt Lock/Resistance Control Knob you can control the amount of friction needed to make your camera and video camera securely stay at any tilt position without locking it into place.
- Turn the Tilt Lock/Resistance Control Knob in a clockwise direction to increase resistance and to lock the head in position.
- Turning the Horizontal Panning Lock Knob in a clockwise direction can lock the head in a position.
- The video head can horizontally pan your camera or video camera 360° and tilt forward 90° and back 40°.

8. Removing the camera or video camera from the Video Head

As shown in Figure 8, loosen the Quick Release Clamp Locking Knob; press the Security Pin Release Button, then slide out the camera and QR plate. You can slide the QR Plate out of the clamp from either side.

9. Removing the QR plate from the Camera or Video Camera

As shown in Figure 4, loosen the screw in a counter-clockwise direction, and take off the QR plate.

10. Storing the QR plate on the Head

As shown in Figure 3, loosen the Quick Release Clamp Locking Knob by turning in a counter-clockwise direction, and slide the QR plate into the clamp. You can slide the QR Plate into the clamp from either side.

11. Removing the head from the tripod or monopod


As shown in Figure 2, tighten the Horizontal Panning Lock Knob, to lock the head and prevent it from turning, then turn the whole head in a counter-clockwise direction, until the head is removed from the tripod or monopod.

12. Placing the head into the storage bag

Please put the head of the VA-5 into the bag first, with the handle towards the pocket mouth. Tighten the bag fastener to close the opening and protect the head.

Specifications are subject to change without notice.

说明书背面：



使用说明
VA-5专业摄像液压云台

广东思锐光学股份有限公司
地址：广东省中山市五仙山第三工业区 邮编：528458
电话：0760-8897373 传真：0760-8507082 服务热线：400 830 2288
邮箱：info@sirui.com 网址：www.sirui.com
服务时间：9:30-12:15, 14:00-18:00

VA-5参数

平衡负重	1
最大负重	3
自身重量	0.6
规格	VA-5 300x120x83 0.6/1.32 3/6.61

保修卡

尊敬的客户：
感谢您购买我们的产品！在您使用过程中，如果发现材料本身的缺陷及工艺制造质量问题，我们将为您提供免费的维修服务。在保修期内，我们将为您提供免费的维修服务。如有质量问题，我们将免费维修。
注意：调节前应先查看云台底座水平珠，确保水平。
售后服务热线：400 830 2288

产品名称	保修期限
云台	6年
防潮柜本体	3年
电子部分	3年

产品编号：_____ 购买日期：_____

姓名：_____ 联系电话：_____

地址：_____

邮编：_____

维修日期：_____

维修人员姓名：_____

维修时间：_____

维修记录表A

用户名	
用户电话	
用户地址	
邮编	
故障描述	
维修日期	
维修人员姓名	
维修时间	

维修记录表B

用户名	
用户电话	
用户地址	
邮编	
故障描述	
维修日期	
维修人员姓名	
维修时间	

1. 注意事项

- 在云台上安装相机或摄像机时，请用手扶稳相机或摄像机，以防意外跌落。
- 在脚架上安装云台时，请用手扶稳云台，以防意外跌落。
- 云台使用环境温度：-20°C ~ +60°C。
- 云台俯仰角度：-60° ~ +90°。
- 调整好平衡后，如果额外安装了配件，需要重新调整水平平衡。

2. 云台的基本结构

3. 安装云台

- 如果您的三脚架是UNC1/4"连接螺丝，那么您需要另外购买一颗UNC3/8"的连接螺丝。
- 如图2所示，把云台底部的UNC3/8"螺丝孔对准脚架上的UNC3/8"螺丝，然后顺时针旋转云台底座至牢固锁紧为止。

4. 快装板从云台上卸下

如图3所示，把快装板锁紧旋钮逆时针方向松开，按下保险按钮，然后把快装板从夹座取出。从夹座的前后两个方向均可拆卸快装板。

5. 快装板安装在相机或摄像机上

如图4所示，根据相机或摄像机安装螺母选取适当的固定螺钉，按顺时针方向锁紧螺钉。

6. 相机或摄像机安装在云台上

如图5所示，把带快装板的相机或摄像机整体沿夹座推入云台，也可从另一个方向推入。注意：手松开相机或摄像机前应确保“保险钉”已回位，相机或摄像机不会从云台上跌落。

7. 相机或摄像机在云台上的平衡调节

如图6所示，调节锁紧旋钮把阻尼调到最小，前后移动快装板位置，观看云台底座上的水平珠，把相机或摄像机调到水平平衡，再锁紧“快装板锁紧旋钮”。注意：调节前应先查看云台底座水平珠，确保水平。

8. 拍摄时云台的使用

- 如图7所示，调节锁紧旋钮在阻尼范围内，通过转动“调节锁紧旋钮”，调整适当的阻尼，使相机或摄像机平稳地停留在任何俯仰位置。
- 顺时针拧紧“调节锁紧旋钮”，可以锁定云台俯仰转动。
- 顺时针拧紧“水平锁紧旋钮”，可以锁定云台水平转动。
- 通过把手操作云台，相机或摄像机在水平方向上可实现360°旋转拍摄；前后俯仰可实现向前90°拍摄，向后60°拍摄。

9. 相机或摄像机从云台上卸下

如图8所示，先松开“快装板锁紧旋钮”，左手按下保险按钮，然后把带快装板的相机或摄像机整体沿夹座从云台取出，也可从另外一个方向取出。

10. 快装板从相机或摄像机上卸下

如图4所示，按逆时针方向松开螺钉，取出快装板。

11. 快装板安装在云台上

如图3所示，把快装板锁紧旋钮逆时针方向松开，把快装板从夹座装回云台。从夹座的前后两个方向均可安装快装板。

12. 云台从脚架上卸下

如图2所示，拧紧水平锁紧旋钮，使云台不能水平转动，然后逆时针旋转云台，直到云台从脚架上旋出。

13. 云台装入云台布袋内

请将云台主体朝下装入布袋内，把手尾朝布袋口，然后收紧袋口，把绳扣拉到袋口处，防止袋口松开。

折叠方法：

