





Clio 172/182 Adapter



Functions assignment



| No. | EMU pin name | Function |
|-----|-----------------------|----------------------------|
| 1 | Analog In #1 | TPS 1 signal |
| 2 | Analog In #2 | TPS 2 signal |
| 3 | Analog In #3 | Accelerator pedal 2 signal |
| 4 | Analog In #4 | MAP signal |
| 5 | Analog In #5 | AC request signal |
| 6 | Analog In #6 | AC pressure |
| 7 | AUX 1 | Fuel pump relay |
| 8 | AUX 2 | Fan 1 relay |
| 9 | AUX 3 | VVT |
| 10 | AUX 5 | AC clutch |
| 11 | AUX 6 | Fan 2 relay |
| 12 | H-bridge #1 winding A | Throttle body motor + |
| 13 | H-bridge #1 winding B | Throttle body motor - |
| 14 | Ignition coil #1 | Coil cyl. #1 and cyl. #4 |
| 15 | Ignition coil #2 | Coil cyl. #2 and cyl. #3 |
| 16 | Injector #1 | Injector 1 |
| 17 | Injector #2 | Injector 2 |
| 18 | Injector #3 | Injector 3 |
| 19 | Injector #4 | Injector 4 |
| 20 | Switch #1 In | Clutch switch |
| 21 | Switch #2 In | Brake switch |