







POWER CONTROLLER SAFETY AND ENVIRONMENT FIRST

DO NOT dispose of electrical equipment with standard domestic waste. Contact your local authority for disposal information specific to your area.

ONLY OPERATE ON A 12V SYSTEM. The unit will be irrepairably damaged if operated at other voltage.

DO NOT adjust the Power Controller while operating a motorcycle, or any other type of vehicle or machinery.

DO NOT allow the unit to be submerged in water.

DO NOT modify or disassemble any part of the system in any way.

DO NOT use if the product is visably damaged, or feels hot to the touch.

This Keis BLUETOOTH Power Controller is suitable for all Keis Heated Jackets, Bodywarmers, and Vests, and other Keis heated garments that do not feature a built-in power controller.

Do not connect this Power Controller in series to a Keis garment that already has a built-in power controller (like the Keis heated motorcycle gloves), as they will cancel each other.

Always connect this BLUETOOTH Power Controller to the provided connectors in the Controller Pocket of the Keis garment you wish to control, and not in between a Keis heated garment and a power source (a portable battery or vehicle power lead). This allows for other garments (like gloves) to be connected to a Keis Jacket, Bodywarmer or Vest without the BLUETHOOTH Power Controller conflicting with the glove's built-in controller.

TECHNICAL DATA

VOLTAGE: 12V only

POWER CAPACITY: 96W maximum



BLUETOOTH Power Controller

SSS KEIS

INSTRUCTIONS

These operating instructions are applicable for the BLUETOOTH Keis Power Controller only.

W54-370889

For the full range of Keis accessories, or further information, please visit the website:

www.keisapparel.com















USING THE POWER CONTROLLER

Locate the Controller Pocket on your Keis heated garment.

This is the vertical zipped pocket on the outside of the left front panel, near the waist, of your Keis Heated Jacket, Keis Heated Bodywarmer, or Keis Heated Vest.

Pull this cable evenly to disconnect the Loop Connector from both its male and female plug connections. Store the disconnected Loop Connector cable carefully, as it will be required for the heated garment to work if you decided to no longer use the Power Controller.

Connect the Power Controller to both the male and female connections within the Controller pocket.

POWER CONTROL WITHOUT USING THE KEIS ICONTROL APP

This BLUETOOTH Power Controller can also be used as a STANDARD Power Controller when operated without using the Keis iControl application. These are the instructions when using this controller without connecting to the Keis iControl application.

When the Power Controller is connected to a powered garment for the first time, all the LEDs on the controller will flash for two seconds.

To SWITCH ON:

Press and hold down the (1) button for one second to switch the controller on. The controller will default to the highest setting (shown by a red LED).

Press the (1) button again to scroll through the settings - medium (amber), low (green), and back to high (red).

To SWITCH OFF:

Press and hold the 🖒 button for at least two seconds to switch off.

POWER CONTROL USING THE KEIS ICONTROL APP

Download the free Keis iControl application on the Google Play store or Apple App Store. When the Power Controller is connected to a powered garment for the first time, all the LEDs on the controller will flash for two seconds.

To SWITCH ON:

Press and hold down the 🖒 button for one second to switch the controller on. The controller will default to the highest setting (shown by a red LED).







Open the Keis iControl App. and press 'Allow' on the pop-up to allow the App to 'Allow Keis iControl to access this device's location?'



Press 'Add' to add a BLUETOOTH Power Controller to the Keis iControl application. A loading screen will appear while scanning Make sure that your **BLUETOOTH Power** Controller is plugged into your garment and switched on.



Once the BLUETOOTH Power Controller has been detected, a 'Press the button on the Keis Controller' status will appear. Press the button on the Keis **BLUETOOTH Power** Controller to confirm this is the device you wish to connect to.



You will be asked to name the device button. Name your device controller buttons when using different Keis garments, with each button connected to a different BLUETOOTH Power Controller.







to cycle through three Power settings: Green = Low Power Amber = Medium Power Red = High Power.

To SWITCH OFF:

To switch the BLUETOOTH Power Controller off, press and hold the O button on the BLUETOOTH Power Controller for at least two seconds.





