BEACHWAVER BACKSTAGE USER GUIDE

OPERATION



Switch Power Button to center.



TO LOCK Switch Power Button up to lock buttons.

OFF:

Switch Power Button down.



COOL SHOT BUTTON

Press for cool air and to seal style.



STYLE TOGGLE BUTTON

Toggles between preset and custom setting.

Dryer Setting: Press once for high-speed. Style Setting: Press twice for low-speed. Custom: Press three times to unlock Speed and Temperature buttons.



SPEED BUTTON When custom setting is

selected press Speed Button to adjust from low to high speed.



₩

TEMPERATURE BUTTON

When custom setting is selected press temperature button to adjust between temperatures: 105°F, 140°F, 175°F, 210°F, 250°F

When button is selected temperature rises. Once at 250°F, if the button is pressed, temperature will lower to 210°F etc.

USER MAINTENANCE

CARING FOR YOUR TOOL The Beachwaver® Blowdryer is virtually maintenance-free. If

surface becomes dirty, unplug tool and, when it is cool, wipe the exterior with a cloth. If anything abnormal occurs, contact Customerservicer@beachwaver.com for support. Do not attempt to repair tool yourself. Attempting to repair tool yourself voids warranty.

STORAGE



Turn off and unplug the Blowdryer. Allow the

WHEN NOT IN USE

tool to cool, and store out of reach of children in a safe, dry location. Never wrap the cord around the tool, as this may

cause premature wear of the cord and may lead to cord damage that is not covered under manufacturer's warranty. Handle the cord carefully to extend cord life,

and avoid jerking, bending or twisting the cord, especially at the plug connection.

360° Magnetic Attachments





Diffuses air in a flow

NOZZLE:

perfect for styling.



When custom setting is selected press temperature button to adjust between temperatures: 105°F, 140°F, 175°F, 210°F, 250°F

Simulates natural drying while reducing

DIFFUSER:


frizz and defining curls. **HOW TO ATTACH**

Easy Controls

To Place On: Select attachment. Hover attachment near nozzle. 360° Magnetic Suction will automatically pull and hold attachment.

To Remove: Turn off and allow to cool. Pull off attachment.

Filter Guard ① To remove, turn dryer off. Allow to Temperature Button cool. Remove magnetic filter.



WARRANTY

welcome the opportunity to make it right!

discretion of the Beachwaver Co.®

At The Beachwaver Co. will replace your styling tool for one year from the date of purchase if the product is defective in materials or workmanship. In no event shall be liable for any special, incidental or consequential damages for breach of this or any other warranty, express or implied, whatsoever. Any implied warranties, obligations or liabilities, including but not limited to the implied warranty of merchantability and fitness for a particular purpose shall be limited to the one-year duration of this written limited warranty. The warranty does not apply in the following scenarios: any unauthorized party opened the product in an attempt to fix the product, normal

wear and tear, purchasing from an unauthorized seller, damage caused by miuse or mishandling, or due to user error. Warranty application is determined in the sole

At The Beachwaver Co.® we want you to be thrilled with our tools. We want you to look and feel beautiful. We believe in the quality of our tools and test each iron thoroughly. We welcome your feedback and, in the event of any problem, we

PLEASE REGISTER YOUR TOOL FOR WARRANTY! Please contact customerservice@beachwaver.com for information

on how to register your iron or to make a warranty claim.