

# S-SERIES

## TRAVEL FRIENDLY

Visit <http://www.beachwaver.com/pages/manuals> for User Guide and full operating instructions. Retain documentation for future reference.



## SAVE THESE INSTRUCTIONS IMPORTANT SAFETY INSTRUCTIONS

When using iron, especially when children are present, basic safety precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING

For tips and tricks on how to use your beachwaver, visit [Beachwaver.com](http://www.beachwaver.com)

**WARNING: The Beachwaver® has a motorized function that, if impaired, could cause serious pain or burns to the scalp. If used improperly or if product malfunctions, discontinue use immediately. If the motor continues to rotate without the control of the Rotation Button, immediately unplug unit, release the clamp and slide hair out. Contact Customer Service for support.**

**WARNING: POSSIBLE ELECTRIC SHOCK. DO NOT IMMERSE IN WATER OR USE WHILE BATHING. SUITABLE FOR DRY LOCATIONS ONLY.**

**AVERTISSEMENT: LA DECHARGE ELECTRIQUE POSSIBLE, N'IMMERGENT PAS OU N'EMPOLOIENT PAS TOUT EN SE BAINANT. UTILISATION AU SEC SEULEMENT.**

**WARNING: The Beachwaver® is an electrical appliance and reaches high temperatures. Use of iron requires constant supervision and should be kept away from water.**

**KEEP AWAY FROM WATER!**

**DANGER – As with most electrical appliances, parts are live even when the switch is off. To reduce the risk of death by electric shock:**

1. Always unplug it immediately after use.
2. Do not use while bathing.
3. Do not place or store iron where it can fall or be pulled into a tub or sink or other vessel containing water.
4. Do not place in water or other liquids.
5. If the appliance falls into water, unplug it immediately. **DO NOT REACH INTO WATER!**

**WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons:**

1. The iron should never be left unattended when plugged in.
2. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
3. This iron is only intended for use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate the iron if it has a damaged cord or plug, if it is not working properly or it has been dropped, damaged or dropped into water. Contact [customerservice@beachwaver.com](mailto:customerservice@beachwaver.com) for more information.
5. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
6. Never use while sleeping.

7. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
8. Never drop or insert any object into any opening or hose.
9. Do not use an extension cord with this appliance.
10. This curling iron and clip are hot when in use. Do not let eyes and bare skin touch heated surfaces.
11. Do not place the heated curling iron directly on any surface while it is hot or plugged in. Use the stand provided.
12. Do not use if hair has been treated with flammable products.
13. Iron will be hot when in use.
14. Do not allow children to use.
15. Do not use iron when you are impaired in any way.
16. Iron must be completely cooled before storing.
17. Do not attempt to touch the surface of the iron, as it is hot and can cause injury, burns or pain. **KEEP AWAY FROM WATER.**
18. Do not use without the assistance of a mirror
19. Do not pull, twist, or wrap cord around the iron.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to alter this safety feature.

#### SERVICING OF DOUBLE INSULATED APPLIANCES

In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be only be qualified service personnel. Replacement parts for a double-insulated appliance must be identical to the parts they replace. A double-insulated appliance is marked with the words "**DOUBLE INSULATION**" or "**DOUBLE INSULATED**." The symbol (square within a square) may also be marked on the appliance.

**This appliance is for household use.**

**WARRANTY:** Please visit <http://www.beachwaver.com/pages/return-policy> for information on how to register your tool or to make a warranty claim. You may also email [customerservice@beachwaver.com](mailto:customerservice@beachwaver.com).

To get the most from your Beachwaver curling iron, follow [@TheBeachwaver](#) for tutorials and tips.

# SAVE THESE INSTRUCTIONS



MADE IN CHINA / FABRIQUE EN CHINE



**TRAVEL-FRIENDLY:** 100-240Vac, 50/60Hz  
Dual voltage. Type A/B plug.

**BEACHWAVER® WATTAGE**

Beachwaver® S.75 38W Beachwaver® S1 50W Beachwaver® S1.25 55W