

— ENGLISH —

Fn Key Combinations

FN+ESC	Restore factory settings
FN+Q	Second Bluetooth 1
Q	Backlight fast blinking
FN+W	Bluetooth 2
W	Backlight blinking fast
FN+E	Bluetooth 3
E	Backlight blinks rapidly
FN+R	2.4G
FN+Q/W/E/R	Toggle connection mode
FN+T	Switch wired mode
FN+~	Power indication
FN+TAB	Backlight switching
FN+Y	SCROLL LOCK
FN+U	PAUSE BREAK
FN+I	INSERT
FN+O	HOME
FN+P	PRTSC SYSRQ
FN+[END
FN+A	WIN SYSRQ
FN+!	Screen brightness -
FN+@	Screen brightness +
FN+#	MULTI-TASK WINDOW
FN+\$	Program List
FN+%	Backlight Brightness -
FN+^	Backlight Brightness +
FN+&	Previous song
FN+*	Pause/Play
FN+(Next song
FN+)	Mute
FN+_	Volume -
FN++	Volume +
FN+S	MAC system
FN+	Backlight Off
FN+DEL	Customize Backlight
FN+↑	Backlight speed +
FN+↓	Backlight speed -
FN+←	Backlight direction switching
FN+→	Backlight color switching

— ENGLISH —

Backlight Customization

- 1 Press FN+DEL for 5 seconds to enter customized mode all backlight off (WIN light blinking indication)
- 2 Customize the light according to your preference.
- 3 Press FN+DEL to enter recording mode to save (WIN lamp off indication)


Charging Indication

- 1 Low battery indication - FN key keeps flashing red when the battery is at 3.3V, and the keyboard shuts down when the battery is at 3.1V.
- 2 Charging indication - when plugging in the TYPE-C cable charging FN key red constant light for 3 seconds and then synchronized with the backlight to indicate charging
- 3 Synchronized with the backlight when fully charged
- 4 Power indicator - press the key combination Fn+~, the backlight is off, the number keys 1 to 0 light up to show the percentage of power, such as: 30% of the following red, 70% of the following blue, 70% of the above green.

Basic Parameters

Data Cable: 1.5M TYPE-C Interface: USB Lighting: RGB
Connection Mode: Bluetooth/2.4G/Wired Data Cable: 1.5M TYPE-C
Keycap: ABS Axis: GATERON Magnetic Switches Battery: 3000MA
Size: 310.37x101.42x40.03mm Weight: 800g
Compatible System: Windows95/98/2000/ME/XP/ Vista/7/8/10, Mac

Dimensions



— ENGLISH —

Steps for Bluetooth Connection

- 1 To activate the pairing of Bluetooth device 1, press and hold FN+Q for 5 seconds, and the lights and backlight will be synchronised with the code successfully.
- 2 To activate the pairing of Bluetooth device 2, press and hold FN+W for 5 seconds, and the lights and backlight will be synchronised with the code successfully.
- 3 To activate the pairing of Bluetooth device 3, press and hold FN+E for 5 seconds, and the lights and backlight will be synchronised with the code successfully.
- 4 Start 2.4G pairing code: long press 5 seconds FN+R key corresponds to the backlight rapid flashing plug the receiver into the PC, pairing code successfully light and backlight synchronisation

Steps for Wired Connection

- 1 To activate the pairing of Bluetooth device 1, press and hold FN+Q for 5 seconds, and the lights and backlight will be synchronised with the code successfully.
- 2 To activate the pairing of Bluetooth device 2, press and hold FN+W for 5 seconds, and the lights and backlight will be synchronised with the code successfully.

