Instructions


Where to get the app:

Please search "scent marketing" in Google play or App store and you will find it.




Note:

- 1. Please make sure that the Bluetooth function is turned on;
- 2. Please make sure that the location function of the mobile phone is turned on.



Bedienungsanleitung AERO

SCENT MARKETING



Reminding



Bluetooth indicator:

As usual, the bluetooth indicator is powered off. After connecting successfully and it will be flashing for reminder.

Battery indicator:


When it lights for 30s stands for full charged, 5s flashing stands for low power and when it always lights, this machine will stop working.

Concentration and Consumption

| Grade | G1 | G2 | G3 | G4 | G5 |
|-------------------|-----|------------|-----|------|-----|
| Intervals (min) | 15 | 13.5 | 12 | 10.5 | 9 |
| Grade | G6 | G 7 | G8 | G9 | G10 |
| Intervals (min) | 7.5 | 6 | 4.5 | 3 | 1.5 |

lotes:

- 1, 500ml oils can diffuse 11000-12500 times under normal circumstances.
- 2. All of the above grade atomization work time is 3 seconds.
- 3. Different grade and oil may with different consumption.



contact our technical personnel. Equipment cleaning

affected.

🗥 Warning

The machine needs to be cleaned when below situations happen:

- 1. You're about to change to another kind of essential oil.
- 2. The atomization volume becomes weak.

1. Please keep the machine vertical. Tilt or lie flatly may cause oil overflow. The machine efficiency may be

2, Shall not modify, disassemble or

repair the machine. If any failure

happens to the machine, please

Cleaning steps:

- 1、Pull out the atomized head, loose the bottle.
- 2. Find a larger container and fill the industrial alcohol up, then soak the atomized head and the bottle for 5-10mins.
- 3. Airing the atomized head and the bottle.

Note:


- 1. After cleaning the device, turn on the unit, press and hold SET button for 3 seconds to reset remaining oil level.
- 2. After spaying 3 seconds, the unit will stop 2 seconds, then it will spray 50 milliseconds for clearing the remaining oil in the atomizer head, it is normal.

Troubleshooting

Before asking to have the machine repaired, please try to diagnose the problem first following to bellow instructions.

| Symptom | Remedy | |
|------------------|---|--|
| Does not diffuse | - Check whether the batteries are loose or in low battery situation If the machine is in "not working period", it stops diffuse Check whether the air pump is normal or not Check whether the gasket is damaged/loose or not. | |
| Spray little | - Check whether the gasket is damaged Check whether the atomized core is plugged or not Check whether the cap of the atomized head is loose or. | |
| Oil spill | - Whether the atomized head is damaged or not. | |
| Abnormal sound | - Pump is loose, install it correctly The pump is damaged, change a new one. | |

Installation



- 1. Insert the key, twirl anticlockwise to unlock the door.
- 2. Tightly connect the atomizer head and the fragrance bottle, and install them to the machine.
- 3. Install the batteries according to the positive and negative terminals.
- Note: 1. When the unit is connected by DC 12V adapter, the batteries stop supplying power, disconnect the DC 12V connection, the batteries start to supplying power.
 - 2. After installing new batteries, the unit will work after 25s.
- 4. Insert the key and twirl clockwise to lock the door.

