

Product Information

The Problem:

There is constant friction between the chain and the sprocket while riding, as well as between the chain links. This loosens fine metal abrasion and the chain inevitably gets dirty. Together with residues from chain sprays, sand, road dirt, etc., a stubborn deposit forms on the chain and sprocket, which extremely accelerates wear. A new lubrication becomes increasingly ineffective as the lubricants can no longer penetrate the chain.

The Solution:



CHAIN BRUSH



NEW


Product Advantages:

Eliminates the heaviest dirt on the entire drive

- Supports the cleaning with the S100 Chain Cleaner
- Removes stubborn dirt
- Different brush heads allow all parts of the drivetrain to be cleaned
- Tough bristles

Application Areas:

For the entire drive



Application:

Apply S100 Chain Cleaner. Then clean the treated areas thoroughly with the brush. Then rinse off the cleaner with a strong jet of water.

Note: After cleaning, treat the chain with chain spray.

RECOMMENDED PRODUCT:



S100 CHAIN CLEANER –
For all highly stressed,
fast-running drive
chains