




MELODY 3 AUTOMATIC

QUICK START



EN Read Safety Precaution booklet before first use.



First use



Preparing a beverage



Recommendations for safe use





Cleaning



Descaling

1		 www.dolce-gusto.com.au			
2			 ON 5 sec		
3			 MAX		
4	 MAX			 OFF	

Descaling at least every 3 - 4 months, depending on water hardness in your region



Troubleshooting



User Manual

NESCAFÉ Dolce Gusto

www.dolce-gusto.com.au

NESCAFÉ DOLCE GUSTO



HOTLINES

AUS 1800 466 975