



ATOMIK KNIGHTZ
BOOMBOX





Enjoy it.

Please read this manual carefully before using

Congratulations and Willkommen! You are now part of the Blaupunkt family. You have chosen German iconic brands premium earbuds and have become a part of an elite group that enjoys and appreciates the finest audio experience.

To get the best performance from your Blaupunkt audio product please read this manual carefully and follow the instructions. This will ensure you get the most out of your Blaupunkt product. Keep the manual safely and refer to it when in doubt.


JUST ONE SCAN
CAN!



One QR Code to access everything - Warranty, Blue Points, Manuals, Service and all you will ever need.


Product Features

- Wireless Bluetooth Connection
- Memory Function: Automatically resumes music from where you left off.
- Multiple Playback Options: Supports Bluetooth, USB drive, TF card, and AUX input.
- Removable Lithium-ion Battery
- IPX6 Waterproof: Safe from rain, humidity, and splashes.
- Supports MP3 Format
- High-Fidelity Speakers: Clear and natural sound quality.
- 1+1 TWS Connection: Connect two speakers together.
- Includes One Wireless Microphone



Button Functions

- 1. Power Button**
- Long press: Turn speaker ON/OFF
- 2. “+” Button**
- Short press: Increase volume
 - Long press: Next song
- 3. “-” Button**
- Short press: Decrease volume
 - Long press: Previous song
- 4. Play/Pause Button**
- Short press: Play or pause music
 - Long press: Connect/disconnect Bluetooth



5. Light Button

- Short press: Change light mode
- Long press: Turn light ON/OFF

6. TWS Button (For Pairing 2 Speakers)

- Short press: Pair or unpair TWS
- Long press: Switch playback mode

7. Bass Boost Button

- Press once:
- 1 beep – Outdoor Mode
- 2 beeps – Indoor Mode
- 3 beeps – Karaoke Mode

8. ECHO Button (Mic Settings)

- First press: Enter mic settings
- Within 5 seconds:
 - Short press “+”: Increase echo
 - Long press “+”: Increase mic volume
 - Short press “-”: Decrease echo
 - Long press “-”: Decrease mic volume

Ports & Jacks

- TF Card Slot: Automatically plays when TF card is inserted
- AUX Input: Standard 3.5mm jack
- USB Port: Automatically plays when USB drive is inserted
- Type-C Port: For charging the speaker

How to Use

1. Bluetooth Connection

- Turn on the speaker
- Search and select “BLAUPUNKT ATOMIK” on your phone’s Bluetooth

2. LED Indicators

- Pairing Mode: White light flashes quickly
- Connected: White light stays on
- Playing Music: White light blinks slowly

3. Charging Indicator

- Charging: Lights move from bottom to top
- Fully Charged: All 4 lights stay on

TWS (True Wireless Stereo) – Connect Two Speakers

Make sure both speakers are the same model.

Method 1:

- Turn on both speakers
- Press the TWS button on one speaker until you hear a beep
- • Then, connect your phone to Bluetooth and play music
- **Method 2:**
- Turn on one speaker and connect it to your phone
- Turn on the second speaker
- Press the TWS button on the first (already connected) speaker until you hear “du-du-du”

Troubleshooting

1. Speaker Turns Off Automatically

- Battery may be low. A 3-beep alert sounds before shutdown. Charge for 4 hours.

2. Music Not Playing from USB/TF Card

- Ensure files are in MP3 format and stored in the main folder (root directory).

3. No Sound When Connected to PC

- Check if your PC is using the correct audio output.

4. Device Not Responding

- Restart the speaker by turning it off and on again.

5. Reset the Device

- Use a thin pin to press the reset hole above the AUX

Charging Instructions

- Use the provided Type-C cable
- Fully charge before first use
- Avoid overcharging for better battery life

Cautions

- ① Please use this product with safety guarantee.
- ② Please do not discard the product in the fire or the high temperature because the built-in battery will cause the explosion easily.
- ③ Please do not rough operation of the product such as wrestling collision,removal or modification of the earphone.
- ④ Please use original accessories. Accidents caused by other accessories will not be covered by the warranty.
- ⑤ Please charge the storage box with the charger of DC5V/1A to avoid burning the product.
- ⑥ Please pull out the charging line in time after charging is completed to avoid leaving the product in the state of charging for a long time.
- ⑦ Please stay away from large WIFI, routers or other high frequency transmitting devices, so as to avoid interference of other signals by the earphones, resulting in music stuck or disconnected.
- ⑧ Please use this product in an effective environment (10 meters). And there should be no physical barrier between the phone and the earphone(such as wall,etc.)
- ⑨ Please keep away from water.
- ⑩ It is recommended to use the product below 80% Volume in order to protect hearing.

Warranty

Warranty Information 1 Year

If you have issue with our product please contact our service center Authorized Service Centre Blaupunkt Speakers

Blaupunkt Authorized Service Center:

Envent World Wide Pvt Ltd.
Khasra, No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037

Email- wecare@blaupunktaudio.in

Whatsapp Chat Support: 8860 022 600

Please submit the following information while claiming product warranty:

- Serial Number
- Date of purchase
- A copy of proof of purchase in case of warranty

Note- Important Information

Please use the original packaging or other suitable packaging to protect the unit in transit.