

**BLAUPUNKT**  
**TRULY WIRELESS EARBUDS**  
**BTW300 PLATINUM**




**Enjoy it.**

Please read this manual carefully before using

Congratulations and Willkommen! You are now part of the Blaupunkt family. You have chosen German iconic brands premium earbuds and have become a part of an elite group that enjoys and appreciates the finest audio experience.

To get the best performance from your Blaupunkt audio product please read this manual carefully and follow the instructions. This will ensure you get the most out of your Blaupunkt product. Keep the manual safely and refer to it when in doubt.



Hybrid ANC	- 42dB
Bluetooth Version	V5.2
Decode	SBC /AAC /CVSD /mSBC/Opus /LC3
Bluetooth Profiles	A2DP 1.3,AVRCP 1.6,HFP,1.7,SPP 1.2, GATT
Play time	9-10 hours
Talk time	7-8 hours
Charging time	1.5 hours
Frequency response range	20Hz ~ 20KHz

**Touch Control Guide as below:**

**Power On**

- Open the charging case the earbuds will automatically power on.
- Press or hold the MFB button for 2s.

**Power Off**

- Put the earbuds back into the charging case and close the charging case.
- Press and hold MFB for 5s (non-working state).

**Remark:** If the Bluetooth connection is successful, manual shutdown is not allowed. If the Bluetooth connection is not enabled, manual shutdown is allowed

**Pairing:**

- Open the charging case, the two earbuds will power on and pairing with each other automatically. Open your Bluetooth device and search “**BLAUPUNKT PLATINUM**” for connection.
- If the earbuds are not connected to the mobile phone or does not connect back to the device within 15s after power on, it will turn off automatically after 5 minutes (except ANC ON mode, which is still under connecting state)

**Play/ Pause Music**

Click the MFB button on L/R earbud once

**Previous track / Next track**

- In binaural mode, double click MFB button on L earbud to previous song
- In binaural mode, double click MFB button on R earbud to next song

**Answer a call/ Hang up a call**

Click the MFB on L/R earbud once

**Reject a call**

Press and hold the MFB button on L/R earbud for 2s during an incoming call

**Cancel a call**

Call outbound status, short press MFB on L/R earbud

Hold the current call and answer the new call

Double click MFB on L/R earbud

**Activate Voice Assistant**

Press the MFB on L earbud for 2s when music stop, repeat to close it

**ANC Operation**

Down-press MFB button on R earbud for 2s to the mode of ANC OFF

Down-press MFB button on R earbud for 2s to the mode of ANC ON

Down-press MFB button on R earbud for 2s to the mode of ANC OFF

Down-press MFB button on R earbud for 2s to the mode of Transparency

**Factory Reset:**

**1. Earbuds enter the state of being searched by mobile phone forcibly**

- L/R earbuds are in the charging case: Long press the charging case reset button for 5 seconds until the charging case LED light flash white quickly, the earbuds will enter the state of being searched by mobile phone.

**2. Clear Earbuds & Phone Pairing list**

- L/R earbuds are in the charging case: Long press the charging case reset for 10 seconds until the charging case LED light flash red quickly. After reset successfully, earbuds will automatically enter the state of being searched (it only clear the pairing record between phone and earbuds, not TWS pairing record)

**3. Clear TWS Pairing Records**

- L/R earbuds are in the charging case: triple click the charging case reset button until charging case LED light flash red quickly to clear the pairing information of the L and R earbud.

**LED Indicator Guide:**

Mode	Description	Voice prompts
Power On	The white LED indicator of the charging box will turn on and flash 5 times then turn off	Power On
Power Off	The white LED indicator of the charging box flash 3s then turn off	Power Off
Pairing	-	Pairing
Connected	-	Connected
Disconnected	-	Pairing
-ANC ON	-	-Noise Canceling on
-ANC OFF	-	-Noise Canceling off
-Transparency	-	-Ambient on
Earbuds charging	When the earbuds are charging, the indicator light of the charging box flash white and will turn off after fully charged	
Charging case	During charging, the red indicator light of the charging box is on, and the light will off after it is fully charged	-
Low power remind	-	Battery Low

**ATTENTION!**

Please be careful while listening to music. Blaupunkt has always ensured that every audio product is powerful and produces massive bass and other audio ranges. Please raise the volume levels slowly and do not play music at full volume levels as this could hurt your ears.

**1 Year Warranty**

If you have any issue with your product please contact our Authorized Customer Care team.

**Blaupunkt Authorized Service Center:**

Envent World Wide Pvt Ltd.  
 Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037

**Email-** wecare@blaupunktaudio.in

**Whatsapp Chat Support:** 8860 022 600

Please submit the following information while claiming product warranty:

-Serial Number

-Date of purchase

-A copy of proof of purchase in case of warranty

**Note-** If you do return the product, please use the original packaging or other suitable packaging to protect it in transit