BLAUPUNKT



2.1 CHANNEL DOLBY SOUNDBAR WITH WIRED SUBWOOFER

Enjoy it.

USER MANUAL

Thank you for purchasing this Sound Bar, Please read this instruction manual carefully before using this product to ensure proper use. Keep this manual in a safe place for future reference.

A compact yet powerful Bluetooth soundbar with sleek looks and excellent audio response. 4 built speakers, 1 woofer provide clarity across a broad frequency range, with crisp highs and deep bass that belie the unit's size. An integral USB port enables playback of MP3/WAV files directly from compatible media, with further flexible input options including Aux, HDMI(ARC), Optical and Bluetooth. A convenient and cost-effective TV audio upgrade that doesn't compromise on performance.

- » Slender and stylish metallic grey design
- » Built-in 2.1 channel amplifier with 3 EQ presets
- » Versatile input options to support a range of devices
- » USB port for MP3 and WAV media playback
- » Remote control and Aux cable included
- » Built-in Dolby decoding technology

Matters Need Attention

- 1. Don't put this product under high temperature wet environment and it will be worse when it is in the rain or crash strongly.
- 2. To reduce the risk or electronic shock or fire, do not remove the cabinet cover simply contact a service professional.
- 3. In the rear occurrence of malfunction, do not attempt to repair the unit on your own. Contact a certified service professional for a proper diagnosis and repair.
- 4. If fragments or liquids fall into device box, please cut off the power right away. And it can be used only after professional staff checks it.
- 5. Don't install the unit in or near a place where it may come in contact with

Technical Specifications and Features

Speaker drivers: 2.25"*4 + 8 "1

Frequency: 55Hz-20KHz±3dB

SNR: >=75dB

Bluetooth version: 5.0+EDR

Bluetooth range: Up to 10m

Connections: HDMI(ARC), OPTICAL, USB 2.0, AUX (3.5mm), AC IN

Support Dobly digital Technology certified

Power supply: Built-in AC100-240V for subwoofer

Accessories

User manual x 1

Remote control x 1

Power Cable x 1

Connect subwoofer cable x 1

Aux Cable x 1

Connections



- **1. HDMI(ARC):** Use to connect compatible devices using a HDMI cable (not provided).
- **2. OPTICAL IN:** Use to connect compatible devices using an optical cable (not provided).
- **3. AUX IN:** Use to connect compatible devices using the 3.5mm 3.5mm stereo jack cable (provided).
- **4. USB IN:** Use to connect a flash drive for direct MP3/WAV playback (FAT32 format and 64GB max).
- 5. SW Out: Connect the subwoofer
- **6. DC IN:** Use to connect the D C power supply

LED display

1. Red LED: Standby mode

3. USB: USB media mode

5. OPT: Optical mode

2. BT: Bluetooth mode

4. AUX: Auxiliary input mode


6. ARC: HDMI(ARC)mode

Remote Control



Button	Function	Button	Function
(h)	Power on/off	MODE	Shifting between BT/USB/AUX/OPT/ HDMI(ARC)
×	Mute or recover the volume	ВТ	Shifting into BT mode In BT mode ,hold to enter pairing mode
TREBLE+	Increase the Treble	USB	Shifting into USB Mode
TREBLE-	Decrease the Treble	AUX	Shifting into AUX Mode
VOL+	Volume turning up	HDMI ARC	Shifting into HDMI (ARC)Mode
VOL-	Volume turning down	ОРТ	Shifting into Optical in Mode
44	Previous track	EQ	Shifting to different EQ
M	Pause/Play	ŋ	USB Repeat Modes
>>	Next track	3D	3D Surround on/off
BASS+	Increase the Bass	BASS-	Decrease the Bass

Control panel keys



- 1. Power ON/ OFF /
- 2. Mode
- 3. Volume turning up/Next track
- 4. Volume turning down/Previous track
- 5. Pause/Play

Dolby Sound

The effect of sound is only noticeable when play music or movie with Dolby resources, especially when the 3D sound is turned on for the Dolby movie.

Input Functions

- » **Power on/off:** Press the Power on/off button on the remote control or soundbar control panel to turn the unit on and off.
- » **HDMI(ARC):** Connect an HDMI ARC compatible device to the HDMI(ARC) port on the soundbar using a HDMI cable (not supplied). Select HDMI(ARC) mode either by pressing the HDMI(ARC) button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until ARC is displayed on the LED display. Ensure HDMI ARC is selected as the TV's audio output, then adjust the volume of soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- » **AUX in:** Connect a compatible device using the 3.5mm 3.5mm stereo jack cable. Select AUX mode either by pressing the AUX button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until AUX is displayed on the LED display. Ensure the connected device is producing an audio signal, then adjust the volume of soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- » **Optical in:** Connect a compatible device to the OPTICAL input on the soundbar using a digital optical cable (not supplied). Select OPT mode either by pressing the OPT button on your remote control or repeatedly pressing the MODE button on the soundbar control panel until OPT is displayed on the LED display. Ensure Optical SPDIF is selected as the TV's audio output, then adjust the volume of the soundbar using the Volume up and Volume down buttons on the remote control or soundbar control panel.
- » **Bluetooth:** Press the BT button on the remote control or repeatedly pressing the MODE button on the soundbar control panel until BT is shown on the LED display. The LED display will flash to indicate that the soundbar is in

Bluetooth pairing mode. Ensure that the device you wish to connect is also in pairing mode and search for "**Blaupunkt Dolby**" in its device list. When the two devices are paired, the LED display on the soundbar will stop flashing and remain constant. (The soundbar will now automatically re-pair with this device whenever it is within range and has Bluetooth turned on.)

- » **USB media mode:** The soundbar is compatible with USB flash drives of up to 64GB(Fat32 format) in size and can play MP3 and WAV audio files directly. Simply insert a compatible drive into the USB port on the back of the soundbar and the unit will automatically switch to USB mode and play the first compatible track. USB repeat mode (also accessed via the remote control) enables single track repeat (ONE), all track repeat (ALL) The media player also has a memory function that will recall and continue from the last-played point when a USB flash drive that has previously been used with the soundbar is reinserted.
- **» Equalizer modes:** The soundbar has 3 equalizer presets, tailored to complement various styles of music. Press the EQ button on the remote to choose between Music (EQ1), Movie(EQ2), News (EQ3).

WARRANTY INFORMATION 1 YEAR*

If you have issue with product please contact our service center.

Authorized Service Center Blaupunkt Speakers

Address: Envent World Wide Pvt Ltd Khasra No- 15/15 (4-16), Village Samalkha. Tehsil Vasant Vihar, New Delhi- 110037 E-Mail: wecare@blaupunktaudio.in | Tel: 1800 843 4333

Please prepare and submit the following information during the telephone or e-mail notification to facilitate the process:

- -Serial number
- -Data of purchase
- -A copy of proof of purchase in case of warranty

Note-Important information:

Please use the original packaging or other suitable packaging to protect the unit in transit.