







#### **Buttons:**

"M": change mode:Bluetooth,FM,USB, TF.AUX

- "+": volume up/next track
- "-": volume down/previous track
- ">II": paly/pause,answer/hang up phone call,TWS



#### 1.Bluetooth connection:

When turning on the bluetooth speaker, it will be in bluetooth mode at first. Opening your bluetooth device and searching for bluetooth name to connect. Once this speaker is paired to your device, it will connect to your device automatically next time if you do not delete the bluetooth memory on your device

### 2.Music Play:

Insert USB drive or micro SD card with MP3 files to enjoy music

.Using the 3.5mm audio cable to connect your phone with the speaker to play music

.Short press"+" to play the next song.Short press"-" to play the previous song

.Long press"+" to increase the volume.Long press "-" to reduce the volume

### 3.Radio Mode:

Insert the charging cable into the DC 5V port to act as an external antenna. Press the "M" button to enter the FM mode. Long press the ">II" button2-3 seconds, it will search channels automatically. After the search is completed, press +/- to switch the radio.

### 4.TWS function:

Turn on two speakers at the same time. When they are in bluetooth mode, Long press one of the speakers' ">|| button 2-3 seconds. Wait for the speakers to connect. Final connect with your bluetooth device.

## 5.Calling:

Click the "▶II" button to answer/hang up the phone call, long press the"►II" button 1-2seconds to reject the phone call.

## 6.Charging:

.Charging voltage and current 5v 0.3A, maximum 5V

.When speaker charging ,the red light on; Lights will be off when it's fully charged.

.Repeat charging and discharging will lead to the decline of battery life, which is a normal phenomenon for all possible rechargable batteries.

#### Notice:

- 1. Use the product for its intended purpose only; 2.Pls store and use this product at room temperature:
- 3.Do not expose this product to rain or wet conditions:
- 4.Do not drop, to advoid the fall of the product damage;
- 5.Do not disassemble and repair the product by yourself;
- 6. The product built-in lithium battery, do not casually discard or put in the fire, so as not to cause danger!

# **Warranty Information 1 Year**

If you have issue with our product please contact our service center Authorized Service Centre Blaupunkt Speakers

#### Address: Envent World Wide Pvt Ltd.

Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037 Tel. 18008434333

Please prepare & submit the following information during the telephone or e-mail notification to facilitate the process.

- -Serial Number
- -Date of purchase
- -A copy of proof of purchase in case of warranty

Note-Important Information

Please use the original packaging or other suitable packaging to protect the unit in transit.

