

 **BLAUPUNKT**

ATOMIK PARTY BOOMBOX PS SERIES



Dear customer:

Thank you for choosing our product. please read all the instructions carefully and retain the manual for future use.

Enjoy it.

Buttons:

1. **M MODE** : Click to change mode:Bluetooth,FM,AUX,USB,TF
2. **+** : Volume up/Next track
3. **-** : Volume down/previous track
4. **⏸** : Play/Pause,Answer/Hang up phone call

Function:

1. Bluetooth connection:

When turning on the bluetooth speaker, it will be in bluetooth mode at first. Opening your bluetooth device and searching for bluetooth name "BLAUPUNKT PS" to connect . Once this speaker is paired to your device , it will connect to your device automatically next time if you do not delete the bluetooth memory on your device

2. Music Play:

- » Insert USB drive or micro SD card with MP3 files to enjoy music
- » Short press "+" to play the next song. Short press "-" to play the previous song
- » Long press "+" to increase the volume. Long press "-" to reduce the volume
- » AUX function: Using the two-in-one cable to connect your phone with speaker, and then click the "M" button change the mode to AUX mode to enjoy music.

3. Radio Mode:

The device has antenna to enhance the signal. Press the " M "button to enter the FM mode. Long press the "▶||" button 2-3 seconds , it will search channels automatically. After the searching is completed, press +/- to switch the radio.

4. Microphone function:

Insert Microphone behind the product, then can sing a song and speak anytime and anywhere.

5.TWS function:

Turn on two speakers at the same time. When they are in bluetooth mode, long press one of the speakers' "▶||" button 2-3 seconds . Wait for the speakers to connect. Final connect with your bluetooth device.

6. Charging:

- » Charging voltage and current DC 5v 0.3A , maximum 5V 1A
- » When speaker charging ,the red light on; Lights will be off when it's fully charged.
- » Repeat charging and discharging will lead to the decline of battery life, which is a normal phenomenon for all rechargeable batteries.

Notice:

- 1.Use the product for its intended purpose only;
- 2.Pls store and use this product at room temperature;
- 3.Do not expose this product to rain or wet conditions;
- 4.Do not drop,to avoid the fall of the product damage;
- 5.Do not disassemble and repair the product by yourself;
- 6.The product built-in lithium battery, do not casually discard or put in the fire, so as not to cause danger!

Warranty Information 1 Year*

If you have issue with our product please contact our service center Service Centre.

Authorized Service Center Blaupunkt Speakers

Address: **Envent World Wide Pvt Ltd.**

Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant

Vihar, New Delhi- 110037

E-Mail: wecare@blaupunktaudio.in

Whatsapp No :  8860022600

Please prepare & submit the following information during the telephone or e-mail notification to facilitate the process:

- Serial Number
- Date of purchase
- A copy of proof of purchase in case of warranty

Note- Important Information

Please use the original packaging or other suitable packaging to protect the unit in transit.