



Soundbar with subwoofer




User Manual

Congratulations and Willkommen! You are now part of the Blaupunkt family. You have chosen German iconic brands premium earbuds and have become a part of an elite group that enjoys and appreciates the finest audio experience.

To get the best performance from your Blaupunkt audio product please read this manual carefully and follow the instructions. This will ensure you get the most out of your Blaupunkt product. Keep the manual safely and refer to it when in doubt.

Remote Control

- 
- (1) **STANDBY:** Press this button to turn OFF the subwoofer.
 - (2) **MODE:** Input button(AUX/USB/TV/SD).
 - (3) **4-8:** To choose 6-8 Historical play.
 - (4) **REPEAT:** Repeat one and all audio play.
 - (5) **VOLUME +:** Increase the volume.
 - (6) **PREV:** To select the song in USB/SD card and to select previous channel in radio station.
 - (7) **VOLUME -:** Reduce the volume.
 - (8) **MUTE:** To mute the sound.
 - (9) **EQ MODE/EQ OFF:** To choose audio equalizer(Applicable only USB/SD input).
 - (10) **NEXT:** To select the song in USB/SD card and to select next channel in radio station.
 - (11) **PLAY/PAUSE:** To play/pause in USB/Memory card, long press (PLAY / PAUSE) for 3seconds to search and save channels automatically in radio station, 20 channels can be saved up at most.

-1-

Control Panel Diagram



- (1) Subwoofer
- (2) Remote Sensor
- (3) POWER- Use to switch ON/OFF
- (4) VOL-/Last Music
- (5) MODE/Play/Pause
- (6) VOL+/Next Music
- (7) Bass out
- (8) DC IN
- (9) AUX IN
- (10) TV IN
- (11) USB Input
- (12) SD Card Slot


SPEAKER		SUBWOOFER	
Driver Size	2inch x 4	6inch	
Impedance	20	40	
Frequency Range	40Hz-20KHz	20Hz-150Hz	

AMPLIFIER	
Channel Separation	45db
Signal to Noise Ratio	75db
Power Requirements	
Voltage	100-240V-(DC 12V 3, 1A)
Frequency	50/60HZ

BT connection: Please adjust item into BT mode by pressing the INPUT key on remote control, then search for item model name on mobile phone, then pair mobile phone and item, then BT connected.

-2-

Back Panel Connection Diagram



The meaning of the symbol on the material, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this equipment at your applicable collection point for the recycling of electrical and electronic equipments waste in the European Union and Other European countries which there are separate collection systems for used electrical and electronic product. By ensuring the correct disposal of this product you will help prevent potentially hazardous to the environment and to human health, which could otherwise be caused by unsuitable waste handling of this product. The recycling of materials will help conserve natural resources. Please do not therefore dispose of your old electrical and electronic equipment with your household waste. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

-3-

ATTENTION!

Please be careful while listening to music. Blaupunkt has always ensured that every audio product is powerful and produces massive bass and other audio ranges. Please raise the volume levels slowly and do not play music at full volume levels as this could hurt your ears.

1 Year Warranty

If you have any issue with your product please contact our Authorized Customer Care team.

Blaupunkt Authorized Service Center:

Ervent World Wide Pvt Ltd.
Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037

Email- wecare@blaupunktaudio.in

Whatsapp Chat Support: 8860 022 600

Please submit the following information while claiming product warranty:

-Serial Number

-Date of purchase

-A copy of proof of purchase in case of warranty

Note- If you do return the product, please use the original packaging or other suitable packaging to protect it in transit