

sonic **B**TM

Quick Start + Instruction Guide

Item: SBBTH3

B•keen style

Wireless Headphones

with on-ear mic & control panel

Welcome

Thank you for choosing this sonicB product. We are driven by a common pursuit of quality and excellence in daring design and bold products. But most importantly, we're inspired by YOU.

That's why we commit to encouraging you
to B – who, what, or where you choose.

B you.

- 1 **Welcome**
 - 1.1 What's In The Box

- 2 **Your Wireless Headphones**
 - 2.1 Getting To Know Your Headphones
 - 2.2 Control Panel Features

- 3 **Quick Start Guide**
 - 3.1 Charging & Powering ON
 - 3.2 Bluetooth Pairing
 - 3.3 Auxiliary Mode

- 4 **Bluetooth Functions**

- 5 **All Features & Contents**

- 6 **Specifications**

- 7 **Troubleshooting & Customer Support**

- 8 **Care & Maintenance**

- 9 **Warranty & Legal**

1 Welcome

1.1 What's In The Box

Guide Booklet



Micro USB Cable



Auxiliary Cable



Headphones



2 Your Wireless Headphones

2.1 Getting To Know Your Headphones

A Head Cushion

Soft cushion for the headphones to rest on top of your head

B Ear Cushions

Soft ear cushions for long listening

C Metallic Coating

For a more durable touch and feel

D Control Panel

This is the main area that controls both microphone functions, volume, & tracks

E Microphone

Answer calls hands-free



2 Your Wireless Headphones

2.2 Control Panel Features

A **Volume (+) / Next Track**

Skip to the next track.
Increase the volume.

B **Multi-Function Button**

This button will do the following

- Power on & off
- Pause & play music
- Answer & hand up calls
- Reject calls
- Redial
- Use of smartphone assistant:
 - Google Assistant™
 - Siri®

C **Volume (-) / Previous Track**

Skip to the previous track.
Decrease the volume.

D **LED Indicator Light**


Indicates if the headphones are on/off, pairing, or charging.

E **Micro USB Charging Port**

This is the area to plug-in and charge your headphones

F **Line-In Input Jack**

This is the area to plug-in your auxiliary cable



3 Quick Start Guide

3.1 Charging & Powering ON

- 1 Connect the Micro USB cable (only use the provided cable) to a computer USB port or a USB wall charger. Plug the other end of the micro USB cable into the Micro USB charging port (E) located on the bottom of the right earcup. While charging the LED indicator light (D) will turn RED and then turn OFF when the battery is fully charged. (this can take approx 2-3hrs)
- 2 Ensure the headphones are turned off, then press and hold the Multi-Function button (B) for about 5 seconds to turn the headphones ON. The headphones will enter Bluetooth pairing mode automatically and emit a tone as the LED indicator light (D) will flash BLUE and RED.





NOTE: please refer to the diagram on 2.2

3 Quick Start Guide

3.2 Bluetooth Pairing

- 1 Ensure the headphones are turned off, then press and hold the Multi-Function button (B) for about 5 seconds to turn the headphones ON. The headphones will enter Bluetooth pairing mode automatically and emit a tone as the LED indicator light (D) will flash BLUE and RED.
- 2 Ensure Bluetooth is enabled on your smartphone or music device. Your device will start searching for wireless devices. The headphones will appear as "sonicB B-Keen" in the list of available Bluetooth devices.
- 3 Select "sonicB B-Keen" The LED will begin to slowly blink blue, and the headphones will emit a tone to indicate that it has been successfully paired with your device.



NOTE: please refer to the diagram on 2.2

3 Quick Start Guide

3.3 Auxiliary Mode

- 1 Ensure the headphones are powered OFF by pressing and holding the Multi-Function button (B) for about 5 seconds to make sure the headphones are now OFF.
- 2 Connect one end of the auxiliary cable to your headphones right earcup- line-in input jack (F) and the other end into your compatible audio device. the headphones will power off automatically when the auxiliary cable is inserted. Note: Buttons and microphone may not work in AUX-in mode



NOTE: please refer to the diagram on 2.2

4 Bluetooth Functions

1 Answer & hang up calls

When there is an incoming call, press the Multi-Function button (B) once to answer the call, press the Multi-Function button (B) once again to hang up the call.

2 Reject calls

When there is an incoming call, press and hold the Multi-Function button (B) for 2-3 seconds to reject the call.

3 Redial last number

Double press the Multi-Function button (B) to call the last number in the list of call history.

4 Pause & play music

When playing music, press the Multi-Function button (B) once to pause music, press the button once again to play music.

5 Next & last track

When playing music, press the Volume (+) / Next Track button (A) once to skip to the next track, press the Volume (-) / Previous Track button (C) once to skip to the previous track.

6 Volume up & down

When in a call or playing music, hold the Volume (+) / Next Track button (A) to increase the volume, hold the Volume (-) / Previous Track button (C) to decrease the volume.

7 Smartphone assistant

Triple press the Multi-Function button (D) to activate voice assistant (Google Assistant™ or Siri®) on your smartphone.

NOTE: please refer to the diagram on 2.2

5 All Features & Contents



TECH ASSISTANT ENABLED:
Works with Google Assistant™
Siri®



FOLDABLE EARCUPS
Perfect for on the go storage



UP TO 20HRS OF WORKING TIME:
Advanced tech for extended
battery life & playtime



RECHARGEABLE BATTERY:
Lithium ion



ENHANCED AUDIO
Upgraded acoustics



BUILT-IN MIC:
Handsfree talking



ON-EAR COMFORT:
Soft ear cushions for
long listening



METAL FINISH:
Special durable coating
for long lasting use



WORKS WITH MAJOR BRANDS
+ OTHER BLUETOOTH DEVICES



MOBILE



TABLETS



COMPUTERS



EXPLORE MORE
visit us at:
sonicbaudio.com

CONTENTS:

- Wireless Headphones
- Micro USB Cable
- Auxiliary Cable
- Quick Start & Instruction Guide

6 Specifications

Specifications:	
FREQUENCY RESPONSE	20Hz - 20kHz
DRIVER UNIT	40 mm
BATTERY	400mAh Lithium Ion
WORKING TIME	Up to 20 hours
CHARGING TIME	2-3 hours
IMPEDANCE	32 ohm
OPERATION RANGE	10m

NOTE:

working time depends on volume levels

- lower volume will prolong your estimated battery life.
- higher volume will decrease your estimated battery life.

7 Troubleshooting & Customer Support

Troubleshooting:	
NO POWER	Recharge your headphones using the included micro USB cable.
MUSIC IS NOT PLAYING OVER BLUETOOTH	Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth. Restart the headphones to reconnect your Bluetooth device.
BLUETOOTH DEVICE WILL NOT RECONNECT WITH THE HEADPHONES	Navigate to your Bluetooth settings menu on your Bluetooth device, tap "sonicB B-Keen" and select "Forget". Now follow the steps to pair your device again.

Customer Support Info:

Any issues or problems please reach us at:
support@sonicbaudio.com

8 Care & Maintenance

- DO NOT expose the unit to liquid, moisture, or humidity to avoid damage to the product's internal circuitry.
- DO NOT use abrasive cleaning solvents to clean the unit.
- DO NOT expose the unit to extremely high or low temperatures as this will shorten the life of the electronic device, destroy the battery, and/or distort certain plastic parts.
- DO NOT dispose of the unit in fire as they may explode or combust.
- DO NOT expose the unit to and/or use sharp objects on the headphones as this will cause scratches and damage.
- DO NOT attempt to disassemble the unit.

In the event that the unit does not function properly, return it to the store where it was purchased.




Li-ion

Do not dispose of Lithium-ion batteries with general waste. Please return it to a battery recycling collection point.

9 Warranty & Legal

- The condition of this warranty and our responsibilities under this warranty are as follows: Supplier's warranty is non-transferable. This warranty is limited to the original purchaser only.
- You must be able to prove the date of original purchase of the unit with a dated receipt.
 - The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
 - The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.
 - Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, earbuds and other accessories.
 - A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.
 - Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.
 - This warranty give you specific legal rights, and you may also have other rights which vary under local laws.

 **Bluetooth** is a trademark on a registered trademark of Bluetooth SIG Inc.

Guidelines for protection of the environment



This appliance should not be put into the domestic garbage at the end of its useful life, but must be disposed of at a central point for recycling of electric and electronic domestic appliances.



This symbol on appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.

Siri® is a trademark of Apple Inc., registered in the U.S. and other countries.

Google Assistant is a trademark of Google Inc.



SonicB™ is a registered trademark of iHip Europe Ltd.

Manufactured & Distributed by:
SonicB, Chartwell House, 292-294
Hale Lane, London, UK, HA8 8NP



MADE IN CHINA