

sonic **B**TM

Quick Start + Instruction Guide

Item: SBWM1

B•extra style

Welcome

Thank you for choosing this sonicB product. We are driven by a common pursuit of quality and excellence in daring design and bold products. But most importantly, we're inspired by YOU.

That's why we commit to encouraging you to B – who, what, or where you choose.

B you.

PRECISE
& SLEEK

CORDED
OPTICAL MOUSE

1 Welcome

1.1 What's In The Box

2 Your Corded Mouse

2.1 Getting To Know Your Mouse

3 All Features & Contents

4 Quick Start Guide

4.1 Mouse Setup

5 Specifications

6 Troubleshooting & Customer Support

7 Care & Warnings

8 Warranty & Legal

9 Notes

1 Welcome

1.1 What's In The Box

Guide Booklet



Corded Mouse



2 Your Wireless Keyboard & Mouse

2.1 Getting To Know Your Mouse

A Left Mouse Button

standard left click to select applications & programs

B Right Mouse Button

standard right click to select pop-up menu of common commands

C Scroll Wheel


roll the scroll wheel to move up or down. It also doubles as a button

D Shift Button:

Press to shift between very fast (free-spinning) and precision (click-to-click) scrolling.

E Back & Forward Buttons:

* Press to flip between Web pages.



*depends on your operating system & settings

3 All Features & Contents



FORWARDS & BACK BUTTONS

advanced tech to get more life out of batteries



ADVANCED WHEEL SCROLLING

precise scroll wheel is faster and quieter



HAND SCULPTED COMFORT

ergonomic design for less hand cramps



EXPLORE MORE

visit us at: sonicbaudio.com



COMPATIBILITY WITH

PC / LAPTOP / DESKTOP

MAC® · WINDOWS® · CHROME™

+ OTHER DEVICES WITH A USB PORT



PLUG & PLAY CONNECTION

no hassles just plug the cord into a free USB port and you are ready to go


Plug the mouse cable into a USB port and wait until the system default driver is installed.

CONTENTS: · Corded Mouse · Quick Start & Instruction Guide

4 Quick Start Guide

4.1 Mouse Setup

- 1 Turn on your computer
- 2 Plug the mouse cable into a USB port and wait until the system default driver is installed.



5 Specifications

Specifications: Mouse	
WORKING DISTANCE	10m (30+ft)
SIDE BUTTONS	2
SHIFT WHEEL BUTTON	YES
SENSOR	Laser-grade optical sensor
SCROLL WHEEL	Yes
ADJUSTABLE DPI	800-1200

6 Troubleshooting & Customer Support

Troubleshooting:	
MOUSE IS NOT RESPONSIVE	<ul style="list-style-type: none">· Check the connection between the mouse and USB port· Try re-inserting your mouse into another USB port on your computer.· Reset your computer and try again

Customer Support Info:

Any issues or problems please reach us at:
support@sonicbaudio.com

7 Care & Warnings

Continuous use of any keyboard may cause injury to hands, wrists, arms, neck or back. If you feel ache, numbness or weakness in these areas, consult a qualified health professional.

TO REDUCE THE RISK OF SUCH INJURIES FOLLOW THESE PRECAUTIONS:

- **Position Yourself:** Choose a chair that provides support for your lower back. Adjust your work surface height and your chair to assume a comfortable and natural body posture.
- **Go Lightly:** Type with a light touch, keeping your hands and fingers relaxed. Avoid resting your palms or your wrists on any type of surface while typing. Don't rest on edges, such as the edge of your desk.
- **Take Breaks:** Take frequent short breaks. Get up and walk around at least a couple of times every hour. Adjust your chair so the seat does not press in to the back of your knees.

WARNING:

- Batteries may leak harmful liquids or ignitable materials or explode causing injury and product damage.
- Do not mix old and new or other battery types.
 - Replace all batteries at the same time.
 - Replace fully discharged batteries immediately.

8 Warranty & Legal

The condition of this warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable. This warranty is limited to the original purchaser only.

- You must be able to prove the date of original purchase of the unit with a dated receipt up to one year.
- The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
- The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.
- Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.
- A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.
- Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.
- This warranty give you specific legal rights, and you may also have other rights which vary under local laws.

Guidelines for protection of the environment



This appliance should not be put into the domestic garbage at the end of its useful life, but must be disposed of at a central point for recycling of electric and electronic domestic appliances.



This symbol on appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.



The information contained herein is subject to change without notice.

Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Mac® is a trademark of Apple Inc., registered in the U.S. and other countries.

Chrome OS™ is a trademark of Google LLC.

All other trademarks are the property of their respective owners.

9 Notes



SonicB™ is registered in Europe as a
trademark of iHip Europe Ltd.

Manufactured & Distributed by:
iHip Europe Ltd., Chartwell House,
292-294 Hale Lane, London, UK, HA8 8NP

MADE IN CHINA

