




## Yealink UVC30-CP900-BYOD Meeting Kit



English | 简体中文

**Quick Start Guide (v1.0)**  
**快速入门指南**

# Package Contents



CP900



Carrying Case



5m USB  
Extension Cable



CP900  
Quick Start Guide

## CP900 Package (USB Speakerphone)



UVC30 Room




Camera Lens  
Privacy Cover



UVC30 Room  
Quick Start Guide

## UVC30 Room Package (Camera)



BYOD



PD  
Power Adapter



1.2m  
USB Type-C Cable



Velcro×2



Type-C to Type-A  
Adapter




BYOD  
Quick Start Guide

## BYOD Package



We recommend that you use the accessories provided or approved by Yealink. The use of unapproved third-party accessories may result in poor performance.

# Connecting Your Devices with BYOD




💡 We recommend that you use a stable 1.8m HDMI cable with magnetic ring to connect the TV.

## Placing Your Devices

Yealink UVC30-CP900-BYOD Meeting kit is suitable for focus and small rooms with 2-7 participants.


Place the CP900 on the center of the table, up to 2m/6.5ft from each participant.










Attach the BYOD box to the bottom or the top of the table.



# Using Your CP900



The CP900 is compatible with Microsoft Teams/Skype for Business client, Zoom client and so on. After connected, you can control the calls on the CP900.



| Task                   | Do  |
|------------------------|---|
| Power on or off        | Hold  for 2 seconds.   |
| Answer a call          | Tap  .   |
| End or reject a call   | Tap  .   |
| Volume up/down         | Tap  /  .                     |
| Mute/unmute microphone | During a call, tap  . The mute LED Indicator and LED light-ring glow red.                                      |
| Hold a call            | During a call, tap  . The LED light-ring flashes green.   |
| Reset to the factory   | Hold  and  for 6 seconds. |

## Teams Button Functions

The Teams button is only applicable when connected to Microsoft Teams client.

| Task  | Do   |
|---|--|
| Activate Cortana/Activate your smartphone's voice assistant | Hold  for 2 seconds.                    |
| Invoke the Teams client                                     | After the Teams client connects, tap  . |

# 包装清单



CP900



拉链包



5米USB  
延长线



快速入门指南

## CP900套件(USB 扬声器)



UVC30 Room摄像机




镜头隐私盖



UVC30 Room  
快速入门指南

## UVC30 Room套件(摄像机)



BYOD盒子



PD  
电源适配器



1.2米  
USB Type-C线



魔术贴×2



Type-C转  
Type-A 转换头




BYOD  
快速入门指南

## BYOD盒子套件



我们推荐使用由Yealink提供或经Yealink认可的配件和线缆,使用未经认可的第三方配件和线缆可能会导致性能的下降。


# 连接BYOD盒子



💡 我们建议您使用稳定的1.8米，带磁环的HDMI线来连接电视。


## 放置设备











Yealink UVC30-CP900-BYOD组合适用于2-7人的小型会议室。  
将CP900放在桌子中间，与每名与会者的距离不超过2米/6.5英尺。  
将BYOD盒子贴在桌子顶部或底部。



# 使用CP900

CP900可以搭配Microsoft Teams/Skype for Business客户端和Zoom客户端等使用。CP900连接至PC后,你可以在CP900上控制通话。



| 任务         | 操作  |
|------------|---|
| 开机/关机      | 长按电源键  3秒。   |
| 接听来电       | 按接听键  。  |
| 挂断电话/拒接来电  | 按挂断键  。  |
| 音量调高/调低    | 按音量调高键  / 调低键  。<br>环形灯带的蓝色LED数增多/减少。 |
| 麦克风静音/取消静音 | 通话中, 按静音键  。<br>静音键红灯常亮, 环形灯带呈红色。  |
| 通话保持       | 通话中, 按接听键  。  |
| 恢复出厂       | 按住接听键  和挂断键  6秒钟。                 |
| 播放音乐/暂停播放  | 当连接上的智能手机播放音乐时, 按挂断键暂停播放; 再次按挂断键  继续播放。  |

## Teams键功能

Teams按键功能仅适用于Microsoft Teams客户端。

| 任务                        | 操作   |
|---------------------------|--|
| 激活Cortana/<br>唤醒智能手机的语言助手 | 长按Teams键  2秒。             |
| 调出Teams客户端                | Teams客户端连接成功后, 按Teams键  。 |

## Regulatory Notices

### Operating Ambient Temperatures

- Operating temperature: +32 to 104°F (0 to 40°C)
- Relative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to +160°F (-30 to +70°C)

### Warranty

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

### Explanation of the symbols

#### ● DC symbol

— is the DC voltage symbol.

#### ● WEEE Warning symbol

To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

### Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

### Safety Instructions

Save these instructions. Read these safety instructions before use!

#### ⚠ General Requirements

- Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crash.
- Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Please refer to the relevant laws and statutes while using the device. Legal rights of others should be respected as well.

#### ⚠ Environmental Requirements

- Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
- Keep the device dry and free of dusts.
- Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.

#### ⚠ Operating Requirements

- Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- Please use the accessories provided or authorized by the manufacturer only.
- The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power socket only.
- Before plugging or unplugging any cable, make sure that your hands are completely dry.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, kitchen sink, wet basement or near a swimming pool.
- During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.

## About Yealink

Yealink is a global leading provider of enterprise communication and collaboration solutions, offering video conferencing service to worldwide enterprises. Focusing on research and development, Yealink also insists on innovation and creation. With the outstanding technical patents of cloud computing, audio, video and image processing technology, Yealink has built up a panoramic collaboration solution of audio and video conferencing by merging its cloud services with a series of endpoints products. As one of the best providers in more than 140 countries and regions including the US, the UK and Australia, Yealink ranks No.1 in the global market share of SIP phones shipments.

## Technical Support

Visit Yealink WIKI (<http://support.yealink.com/>) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (<https://ticket.yealink.com/>) to submit all your technical issues.

- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.

#### ⚠ Cleaning Requirements

- Before cleaning the device, disconnect it from the power supply.
- Use a piece of soft, dry and anti-static cloth to clean the device.
- Keep the power plug clean and dry.

#### Troubleshooting

The unit cannot supply power to device other than Yealink device.

There is a bad connection with the plug.

1. Clean the plug with a dry cloth.
  2. Connect it to another wall outlet.
- The usage environment is out of operating temperature range.

1. Use in the operating temperature range.

The cable between the unit and the Yealink device is connected incorrectly.

1. Connect the cable correctly.

You cannot connect the cable properly.

1. You may have connected a wrong Yealink device.

2. Use the correct power supply.

Some dust, etc., may be in the port.

1. Clean the port.

Contact your dealer or authorized service facility for any further questions.

#### FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### IC Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) this device may not cause interference; and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device. CAN ICES-3(B)

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. NMB-3(B)


#### Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

#### Contact Information

YEALINK NETWORK TECHNOLOGY CO.,LTD.  
309, 3rd Floor, No.16, Yun Ding North Road, Huli District, Xiamen City, Fujian, P.R.C  
YEALINK (EUROPE) NETWORK TECHNOLOGY B.V.  
Strawinskylaan 3327, Atrium Building, 8th floor, 10772X Amsterdam, The Netherlands  
YEALINK (USA) NETWORK TECHNOLOGY CO., LTD.  
999 Peachtree Street Suite 2300, Fulton, Atlanta, GA, 30309, USA  
Made in China



430104001290

