
# B&W TOW & STOW<sup>™</sup>


STOWS UNDER THE VEHICLE WHEN NOT IN USE





#### **Rotate the Ball**

To the Desired Size



## Adjust the Height

Raise or Lower



### **Stow the Hitch**

Under the Vehicle







# B&W TOW & STOW<sup>™</sup>

STOWS UNDER THE VEHICLE WHEN NOT IN USE







AVAILABLE BALL COMBINATIONS















AVAILABLE **FINISHES** 

