







Instalační návod  
Inštalacný návod  
Mounting Instruction  
Montageanleitung  
Инструкция по установке


**SIKOTGVZ150**






20		21	
22		23	
24	Cleaning Wipe	25	


1 x1	2 x4 M4x8	3 x1 RH	4 x1	5 x12	6 x1 TOP	7 x1	8 x4	9 x4 ST4x40
10 x1	11 x4	12 x1	13 x2	14 x1 RH	15 x1	16 x1	17 x1 RH	18 x1 BOTTOM
19 x1	20 x1 LH	21 x1 LH	22 x1 LH	23 x1	24 x1 Cleaning Wipe	25 x1 4mm		










Poznámka: Vnitřní strana koutu  
- Easy Clean

①





②









# 7







# 8



9





10






23

11



12



13

