












Assembly Instruction

If you need extra help with the assembly or think there's a part missing, please visit the support page at 4seasons.co.nz or call us on 03 547 0770.

Part List

Part code	Picture	Name	Qty
A		Back	1
B		Seat	1
C-L		Left Armrest	1
C-R		Right Armrest	1
D		Bolt Cover	6
E		Bolt M8x35	4
F		Bolt M8x20	2
G		Washer	6
H		Wrench	1
I		Seat Cushion	1
J		Back Cushion	1

