









Assembly Instruction

If you need extra help with the assembly or think there's a part missing, please visit the support page at 4seasons.co.nz or call us on 03 547 0770.

Part List

Part code	Pictrue	Name	Qty
A		Table Rim	1
B		Table Leg	4
C		Washer	8
D		Bolt M6x45	8
E		Bolt Cover	8
F		Wrench	1
G		Spring Washer	8



A

