







# Assembly Instruction

If you need extra help with the assembly or think there's a part missing, please visit the support page at [4seasons.co.nz](http://4seasons.co.nz) or call us on 03 547 0770.

## Parts list

Part code	Picture	Qty
A		1
B		1
C		4
D	 M6X50mm	4
E		4
F		1

