












Assembly Instruction

If you need extra help with the assembly or think there's a part missing, please visit the support page at 4seasons.co.nz or call us on 03 547 0770.


Part List

Part code	Picture	Name	Qty
A		Table Top	1
B		Table Leg	2
C		Support Tube	1
D		Glass	1
E		PVC Bolt Cover	10
F		M6X20MM Bolt	2
G		M6X25MM Bolt	4
H		M6X35MM Bolt	4
I		Steel Washer	10
J		Wrench	1

STEP 1



STEP 2



STEP 3

