

TANNING
essentials® SIMPLE TANNING SYSTEMS *built purposely for a perfect spray tan.*

MOBILE TURBO TWISTER - TRAINING MANUAL

mobile turbo twister



AUSTRALIA | CHINA | UNITED KINGDOM | USA

www.tanningessentials.co

TANNING essentials[®]

WELCOME

Thank you choosing the Tanning Essentials Mobile Turbo Twister. Please read the following to help you with the set up and maintenance of your new clean air system.

QUICK SET UP GUIDE


The Tanning Essentials Turbo Twister Mobile contains:

- 1 x Mobile Turbo Twister
- 1 x Power Cord
- 1 x Spare Replacement Filter



TANNING
essentials.

MOBILE TURBO TWISTER SYSTEM



AUSTRALIA | CHINA | UNITED KINGDOM | USA

www.tanningessentials.co

TANNING essentials[®]

MOBILE TURBO TWISTER SYSTEM

1. Un-pack system from packaging
2. Connect the power cord to the socket located on side
3. Turn on just prior to starting the spray tan session. The Blue LED light will indicate power is on.

IMPORTANT NOTE: Position the unit directly behind where the spraying will take place. Combine with a Tanning Tent for optimum performance.



HOW TO CHANGE FILTERS

Filters must NOT be washed, they must be replaced after approximately 60-100 sprays, depending on spray technique

IMPORTANT NOTE: When solution starts to become visible on the backside of the filter or the performance of your unit is not at its usual standard this indicates that they are due for replacement.

Always keep spare filters on hand. Re-order code: TE301101 Turbo Twister Mobile Filters 4 Pack.

- 1 To remove filter simply peel off the used filter from the fitting at the front of the unit. It's a good idea to use gloves when removing the filter to avoid excess solution staining your hands.
- 2 To replace simply insert filter into the front of the unit, ensuring it has been positioned correctly into the fitting that holds it in place by pressing down on both corners and the middle



TANNING essentials®

TROUBLE SHOOTING

If you are experiencing problems with this unit please refer to the table below to assist with troubleshooting. If this table does not provide a resolution to the fault you are encountering please contact your supplier for assistance.

PROBLEM	CAUSE	WHAT TO DO
The unit is not on.	The power cord is not plugged in correctly or the turned on at the wall socket.	Ensure the power cord is properly connected to both the wall and unit socket while turned on.
The unit is not drawing in the tanning overspray.	The filter is full of spray tan. Unit has not been placed directly behind the client.	Insert new filter into the front of the unit. The filters need to be replaced between 60-100 sprays. Place directly behind client for best results. Additionally combine with a tanning tent for best results.
The unit has overheated.	Mobile unit overheated from prolonged use. The filter is full preventing the motor to work correctly.	Place aside until unit has cooled down. Change the filter. Contact your supplier if the unit no longer operates.