



TIGER KING

E-Mail: support@tigerkingsafe.com

Facebook: [@TIGERKINGSAFES](https://www.facebook.com/TIGERKINGSAFES)

Messenger: [m.me/TIGERKINGSAFES](https://www.m.me/TIGERKINGSAFES)



TIGER KING

USER MANUAL XH-1



V.202112

TIGER KING HOME/OFFICE SAFE



MANUAL

- | | | | |
|------------|----------------------------|------------|--------------|
| 01/ | STRUCTURE | 02/ | PACKING LIST |
| 03/ | OPEN THE SAFE | 04/ | CODE SET |
| 06/ | CLOSE THE SAFE
DATE SET | 07/ | RECORD CHECK |
| 08/ | ALARM SET | 09/ | MOUNTING |
| 10/ | CUSTOMER SERVICE | | |

WARNING

**DO CLOSE THE DOOR BEFORE YOU MOVE THE SAFE.
DO KEEP RECORD OF THE NUMBERS ON THE KEY IN CASE OF LOST.**


If you experience any problems or challenges with your safe, please contact us. Many issues can be resolved quickly without the product being returned. Our customer care team is available at SUPPORT@TIGERKINGSAFE.COM to answer your questions.

E-Mail: support@tigerkingsafe.com

Facebook: [@TIGERKINGSAFES](https://www.facebook.com/TIGERKINGSAFES)

Messenger: [m.me/TIGERKINGSAFES](https://www.m.me/TIGERKINGSAFES)

STRUCTURE



TIGERKING I01

PACKING LIST



Inside the safe:



NOTICE:

1. Please follow the instructions;
2. Keep the keys in a secure place rather than inside of safe;
3. Replace the batteries when the screen shows"-LO-BATTE";
4. Mount the safe.
5. Do not move the safe while the door is opening.

TIGERKING I02

OPEN THE SAFE

Two Ways To Open The Safe


THE MASTER KEY IS ALWAYS NEED TO OPEN THE SAFE.

◆ **FIRST WAY - Master key plus emergency key:**

STEP 1: Located the master keyhole by sliding the cover to the left and insert the master key then turn clockwise.

STEP 2: Located the emergency keyhole by sliding the cover to the right (refer to the picture), then fully insert the emergency key and turn counterclockwise.

STEP 3: Turn the knob clockwise to open the door.




◆ **SECOND WAY - Master key plus code:**

For first using , please prepare 4 X AA batteries (not include) and install into the external battery box, plug it into the jack to power the keypad (the jack is in bottom of the keypad) .

STEP 1: Located the master keyhole by sliding the cover to the left and insert the master key then turn clockwise.

STEP 2: Press "#" to wake up system, enter your set code (if you haven't set up the code, please enter the default master code 123456 or user code 1234), press "#" to confirm. If the code is correct, the screen will show "OPEN";



STEP 3: Turn the knob clockwise within the screen lights on to open the door. After opening the safe for the first time, please install 4XAA batteries into the inner battery compartment (which is in the top of the door) .

NOTICE:

1. 10 seconds without any operation, the keypad will go back to standby status, all the operations are invalid;
2. Clear function: Press "*" to clear the last digit you have input;
3. Security display feature: Press "#" to wake up system, and press "*" before inputting the code, any digit you enter will show "□". This function is one-time, you need to reset before entering code next time.
4. The external battery box is for emergency case such as the inner batteries run out, after opening the safe , please install batteries into the inner battery compartment .

CODE SET


◆ **Master Code Setting:**

STEP 1: Keep the door opening. Wait until the screen is in standby status(all lights turn off) and then press "#", the screen will show "-----" ;

STEP 2: Input "00" and then press reset button (a white button hidden inside the battery compartment , please refer to the picture), the screen will show "-----";

STEP 3: Input the new master code (1 to 8 digits) and press "#";

STEP 4: The new code will be confirmed by showing "into".




◆ User Code Setting:

STEP 1: Keep the door opening. Wait until the screen is in standby status(all lights turn off). Press reset button (a white button hidden inside the battery compartment), the screen will show "-----";


STEP 2: Input the new user code (1 to 8 digits) and press "#";

STEP 3: The new code will be confirmed by showing "into".



NOTICE:

1. 10 seconds without any operation, the keypad will go back to standby status, all the operations are invalid;
2. The Default Master code and user code will be defective until new code set. To protect your valuables, please do change code once receive safe;
3. Test the code before you close the door. If the code is correct, the screen will show "OPEN".



CLOSE THE SAFE

Close the door, rotating the knob counterclockwise to lock the door. Then counterclockwise turn the master key to the limit and pull out. Store the master key in a secure place.

DATE SET

STEP 1: During standby status, press "*" to set date.


STEP 2: Press the numbers to adjust the values

For date , it shows as Year--Month--Date

For week, it shows as Week NO. 1 = Monday, 2=Tuesday...

For time , it shows as Hour : Minute

11 numbers in total. It will confirm and save automatically then go back to standby status(screen turns off).



NOTICE:

1. System can not identify the invalidity of entering, please ensure your entering is valid.
2. 8 seconds without any operation, the keypad will go back to standby status, all the operations are invalid.
3. The code and record of opening door will not be lost after power failure, but you need to reset the time and date after power restoration.

RECORD CHECK

The system can keep max 35 opening records, exceed this limit, the first one will be covered by next one.

◆ Record Checking:

STEP 1: Enter Master code or user code, the screen will show "open";


STEP 2: Press "0" or "8" to check the records after the word "open" disappear but before the screen turns off .

STEP 3: The screen will show as per below:

First screen: PASS1 OR PASS2, and record number.
PASS1 means user code, PASS2 means master code, the record number will be shown in the top of right corner of screen.

second screen: Date and time of this opening record.

STEP 4: Press "0" to check the last one, press "8" to check the next one.



NOTICE:

If use emergency key plus masterkey to open the safe, the system will not keep the opening record.

ALARM SET

◆ Dual Alarm System:

1ST: Three continuous incorrect code entering will activate the Alarm. It will last 1 minute until correct code entering . After alarm stopped , the warning system is still on working.

2ND: Vibrate Alarm.


This alarm only activates after manual setting.

STEP 1: During standby status, press "0" , the screen will display "Alert on ". The safe will alarm once be punched or shocked.

STEP 2: Enter the correct code and press #, the alarm will be deactivated .

NOTICE:

1. The Vibration Alarm will be deactivated after correct code entering, you need set again for next time .
2. 10 seconds without any operation, the keypad will go back to standby status, all the operations are invalid.




Mount the safe in place which is not to be moved.

- Drill holes for expansion bolts (or clamping screws) at the proper place;
- Turn the expansion bolts counterclockwise to separate;
- Use the expansion bolts (or clamping screws) to secure the case to the wall or the floor;
- Make sure the case is mounted in place as required and then tighten all screws.

NOTICE:

- 1.For concrete walls, expansion bolts are recommended; for wooden walls, clamping screws are recommended;
- 2.The clamping screw is not included, you need prepare by yourself.



Professional, Efficient, Competitive

Where could I find the instruction video? To see the tutorial video:

1. Go to our Facebook :@TIGERKINGSAFES
2. Go to our Youtube channel:
<https://www.youtube.com/channel/UC7II4xZAK3s-cGA3JgmI9VA>
3. Contact us to get the videos (24/7):
Messenger: [m.me/TI.GERKINGSAFES](https://www.facebook.com/TIGERKINGSAFES)
Email: Support@tigerkingsafe.com

What should I do if I lose the keys?

You need to provide following information to us :

- 1.Your order details;
- 2.The numbers on the key.

Customer Support /Warranty

The possible problem you might meet:

1. Cargo damaged
 2. Missing accessories
 3. Unsatisfied with the safe
 4. Or any other setting problem
- We encourage you to contact us (24/7):
Messenger: [m.me/TI.GERKINGSAFES](https://www.facebook.com/TIGERKINGSAFES)
Email: Support@tigerkingsafe.com