

TANKAssembly Guide

VERSION: XTTM4-PH & XTTM4GT-PH

ITEM	PART NUMBER	DESCRIPTION	QTY
1	5585401	ASSY, TWO BRAKE FRAME	1
2	5553001	WHEEL, 12" DIA X 3.5 WIDE	4
3	2011201	WASHER, STEEL 12.7 ID-40 OD-4 THK CLEAR ZINC	4
4	2010901	WASHER, LOCK M12 SAE ST ZN	12
5	2011301	SCREW, M12-1.75 X 30L SOC HD GR 12.9 CLEAR ZINC	4
6	55726PA	PTD ASSY, RIGHT PUSH HANDLE	2
7	55724PA	PTD ASSY, LEFT PUSH HANDLE	2
8	5572101	WLDMT, HOR PUSH HANDLE	2
9	2010501	WASHER, STEEL 10.5 ID-20 OD-2 THK CLEAR ZINC	4
10	2012801	SCREW, M10-1.5 X 25L SOC HD GR 12.9 CLEAR ZINC	4
11	2010801	WASHER, STEEL 12.7 ID-25 OD-2 THK CLEAR ZINC	8
12	2010701	SCREW, M12-1.75 X 85L SOC HD GR 12.9 CLEAR ZINC	8
13	56024PA	PTD ASSY, TANK WEIGHT HORN	2
14	5433701	SPACER, FLANGE (OPTIONAL)	8
15	5602701	BUMPER, TANK (OPTIONAL)	4
16	XTSA-101	TANK SWIVEL ATTACHMENT (OPTIONAL)	1
17	XTM4-RPK-101	RAIL PULL KIT, TANK M4	1

TABLE OF CONTENTS:

TANK ASSEMBLY: PAGES 3 - 5

TANK CHAIN ADJUSTMENT: PAGES 6 - 9 & 11 - 13

TANK BELT ADJUSTMENT: PAGES 6 - 8 & 10 - 13

TANK WEIGHT HORN KIT (OPTIONAL): PAGES 14 - 15


TANK SWIVEL ATTACHMENT (OPTIONAL): PAGES 16 - 18

TANK BUMPER KIT (OPTIONAL): PAGES 19 - 20


RAIL PULL KIT (OPTIONAL): PAGES 21

INSPECTION & LUBRICATION: PAGE 22

NOTICES: PAGE 23





STEP 1



NOTE:


SECURELY tighten all bolt connections in this step.






NOTE:


LOOSELY tighten bolt connections in this step.








NOTE:

After this step has been completed, <u>SECURELY</u> tighten all bolt connections in this step and previous step.











CHAIN ADJUSTMENT



NOTE:


The chain tension on TANK is pre-set at the factory. However, if the chain becomes too loose or is too tight, then please follow the steps in numbered numbered order to adjust.


BELT ADJUSTMENT




NOTE:


The belt tension on TANK is pre-set at the factory. However, if belt is too loose or starts to slip, then please follow this step.








XTWHK WEIGHT HORN KIT (OPTIONAL)



NOTE:




NOTE:

SECURELY tighten all bolt connections in this step.


Handles have been hidden for assembly clarity.

XTSA TANK SWIVEL ATTACHMENT (OPTIONAL)



NOTE:

XTSA TANK SWIVEL ATTACHMENT (OPTIONAL)




NOTE:


SECURELY tighten all bolt connections in this step.

Handles have been hidden for assembly clarity.


XTSA TANK SWIVEL ATTACHMENT (OPTIONAL)



NOTE:




XTBK TANK BUMPER KIT (OPTIONAL)



NOTE:

Once all bumpers have been assembled, **SECURELY** tighten all bolt connections.

RPK RAIL PULL KIT (OPTIONAL)



NOTE:

SECURELY tighten all bolt connections.

INSPECTION & LUBRICATION

INSPECTION:

Recommended tire inflation: 30 PSI

Once a month, check for loose bolts on handles, wheels and weight horns (optional) as indicated. Tighten if necessary.

Once a month, check that the chain and sprockets are clean, free of rust, dust and grime. Make sure that the chain is properly lubricated. If chain is loose, retighten chain as outlined on page 9.

Once a month, inspect belt. Make sure the belt is not worn, frayed or loose. Replace belt if worn or frayed. If belt is loose, re-tension belt as outlined on page 10.

LUBRICATION:

Once a month, the sprockets should be cleaned and the chain should be lubricated.

RECOMMENDED LUBRICATION: Use a Dry lubrication for indoor use, and wet lubrication for outdoor use. Most bicycle shops carry a variety of different lubricants and can recommend a lubricant based on the conditions where the TANK will be used.

